


Traditional Music Stand Assembly Instructions

TO ASSEMBLE PLEASE FOLLOW PROCEDURES 1-9 AS SHOWN IN THE ILLUSTRATIONS.

1

LIFT DESK SECTION UPRIGHT


SLACKEN OFF NUT



2

DO NOT OPEN THE DESK SECTION YET

TIGHTEN LOCKING NUT




3

DO NOT OPEN THE DESK SECTION YET

SLACKEN OFF LOCKING NUT & PULL LEGS INTO A SPREAD POSITION
RE-TIGHTEN LOCKING NUT

DOWN




4

SLACKEN OFF LOCKING NUTS

ADJUST TO HEIGHT REQUIRED


RE-TIGHTEN LOCKING NUTS



IMPORTANT! FOLLOW STEPS 5-9 IN SEQUENCE.


DO NOT FORCE THE MUSIC DESK TO OPEN OTHERWISE DAMAGE MAY OCCUR. TO FOLD AWAY YOUR STAND, FOLLOW THIS PROCEDURE IN REVERSE ORDER 9-1.

5



GENTLY PULL ALL FOUR ARMS TO AN UPRIGHT POSITION


6



LONGEST TWO ARMS STAY IN UPRIGHT POSITION

SHORTEST TWO ARMS TO BE GENTLY BROUGHT DOWN

7



SHORTEST TWO ARMS STAY IN DOWNWARD POSITION


NOW GENTLY OPEN THE DESK SEE 7 & 8

DO NOT HOLD THE LONG AND SHORT ARMS WHEN OPENING THE DESK

8



9



ADJUST MANUSCRIPT RETAINING ARMS TO REQUIRED POSITION