


ChargeTime™

User Guide



Using the Alarm

1. Slide the switch to alarm **SET**, time will flash.
2. Press **HOUR** and/or **MINUTE** button to set the wake up time.
3. Slide the switch to alarm **ON** to confirm the alarm time. The alarm **LED** with light up.
4. To turn the alarm off, slide the switch to **OFF**.



Adjusting the Brightness

Press **SNOOZE / DIMMER** to adjust the display brightness.



Dual USB Charging

This device includes two USB ports so you can charge two devices at once. The bottom USB charger is more powerful and will charge your devices faster.

