megamaster

TRAVERSE

PORTABLE CHARCOAL BRAAI

ASSEMBLY & OPERATING INSTRUCTIONS



BRAAI USAGE INFO

Never use your braai in enclosed areas like garages, sheds, or any other enclosed areas.

Do not use overhead combustile surfaces / combustile areas.

The minimum air space clearance to combustible construction is 1 m from both the sides and back of the unit.

Do not operate this appliance within 1 m of any structure, fences, over hanging branches or combustible material.

Do not operate this appliance within 7.5 m of any flammable substance.

This braai is not intended for installation in recreational vehicles or boats.

For outdoor use only, on a suitable surface.

HANUAL HORE COMPLETING YOUR BRANCH

WARNING!










DON'T TOUCH ANY BRAAI PART WHILE IN OPERATION



WAIT TILL BRAAI HAS COOLED DOWN BEFORE TOUCHING







DO NOT LEAVE THE BRAAI UNATTENDED, WHEN IN USE.

OPERATIONAL WARNINGS

*	AIRFLOW: Do not obstruct the air vents or combustion flow
	USAGE : Use charcoal or briquettes. Cook before the charcoal or briquettes have a coating of ash.
**	CHILDREN & PETS: Never leave children or pets unattended near the braai. Keep them away from the appliance at all times. Keep items that may interest children away from the braai.
	CLOTHING: Avoid loose garments or synthetic fabrics that may catch fire.
W	FLAMMABLE MATERIALS: Avoid contact between clothing, pot holders, or flammable materials and hot surfaces until the braai has cooled. Do not light the fire if lighting fluid has spilled on clothing or re-light with fluid.
	FOOD CONTAINERS: Never heat unopened food containers on the braai. They could burst from pressure.
•	GREASE: Let grease cool before handlin cleaning.
	POT HOLDERS: Only use dry pot holders; avoid towels or bulky cloths.
	PROTECTIVE GEAR: Wear protective gear when opening the braai lid. Never lean over an open braai or try to move a braai once lit.
%	REPAIRS & SERVICES: Only repair or replace parts as specified in the manual. For other services, contact a qualified technician.
ΨU . 1 1 1 4	SUITABLE COOKWARE: Use only approved glass, ceramic, or glazed utensils. Follow manufacturer guidelines for temperature settings.
\oslash	PROTECTIVE GEAR: Wear protective gear when opening the braai lid. Never lean over an open braai.
	DANGER: Do not use spirits or petrol for lighting or relighting! Use firelighters.
4	FLARE-UPS: Keep a water sprayer handy to extinguish the flame.

PRODUCT SPECS

Dimensions: 60.5 cm (L) x 71.4 cm (W) x 88 cm (H)

Primary Cooking Area: 2 167 cm²

Material: Steel

Weight: 8.86 kg



Z

03	Braai Usage Info
04	Operational Warnings
04	Product Specs
05	Tools Needed
05	Hardware Pack List
05	Part Lists
07	Part Diagram
08	Spare Part List
09	Assembly Instructions
14	Installation Checklist
14	Lighting Instructions
15	Care & Maintenance
15	Warranty

BRAAI

PRONOUNCED: B-R-Y-E

A **braai** isn't just about cooking meat; it's about cooking up **memories** that last a **lifetime**, it's practically an **art** form, a **celebration**, and a way of life! Every flame flickering on the grid is a spark of **laughter**, of **stories** shared, of **friendships** built and strengthened over sizzling boerewors and juicy steaks.

CONTACT INFO

CUSTOMER SERVICE DEPARTMENT

Tel: +27 (12) 802 1515, CAT Monday - Thursday: 07:30 - 17:00


Friday: 07:30 - 14:00

Email: info@megamaster.co.za Website: www.megamaster.co.za



TIME OASSEMBLE H FIRE UP H SW H

TOOLS NEEDED





Some parts have preinstalled screws. Loosen and tighten for final assembly.

HARDWARE PACK LIST


A x 1	B x 9	C x 2	D x 9	E x 9	F x 9	G x 17
5/32-32 x 25/64" (M3.96-9.9mm)	5/32-32 x 1/4" (M3.96-6.3mm)	W1/4-20 x 1/2" (M6.35-12.7mm)	1/4" (M6.35)	1/4 (M6.35)	1/4" (M6.35)	1/4" (M6.35)

PARTS LIST







PART DIAGRAM





SPARE PART LIST


No.	Part (Description)	Warranty coverage	Qty.	No.	Part (Description)	Warranty coverage	Qty.
1	Front Leg - Bottom	ont Leg - Bottom 1 2 10 Lid Hinge, Right-Long		1	1		
2	Rear Leg - Bottom	1	2	11	Lid Hinge, Left-Long	1	1
3	Firebox with leg assembly	1	1	12	Lid Hinge, Right-Short	1	1
4	Leg stop support plate	1	1	13	Lid Hinge, Left-Short	1	1
5	Cooking grid support bracket-A	1	2	14	Charcoal pan	1	1
6	Cooking grid support bracket-B	1	2	15	Cooking grid	1	1
7	Lid	1	1		Manual		1
8	Lid handle	1	1		Hardware pack		1
9	Lid Exhaust Damper assembly	1	1				



































INSTALLATION CHECKLIST

Assemble instructions have been followed.
All packaging has been removed.
Legs stand securely.
Braai is in a suitable position, on a level surface.
Braai is away from areas where it can catch fire.



ALWAYS WHERE GLOVES WHEN HANDLING BRAAI.


LIGHTING INSTRUCTIONS

ONLY USE CHARCOAL LIGHTING FLUID APPROVED FOR LIGHTING CHARCOAL. DO NOT USE GASOLINE, KEROSENE, ALCOHOL, OR OTHER FLAMMABLE MATERIAL FOR LIGHTING CHARCOAL.

Step-by-step guide for lighting your braai:

- 1. Place 3–4 firelighters in the center of the charcoal grate.
- 2. Light with a match or long safety lighter.
- 3. Arrange charcoal/briquettes around the burning blocks in a pyramid shape.
- 4. Add more charcoal/briquettes as needed.
- 5. Once burning well, spread the coals evenly.
- 6. Fire is ready when:
 - Day: Coals are covered in grey ash.
 - Night: Coals have an even red glow.
- 7. Fit the cooking grill securely—ensure crossbar supports lock behind retaining edges.
- 8. Add small amounts of charcoal/briquettes during cooking to extend cook time.
- 9. Lightly oil the grill before cooking to help prevent food sticking.
- 10. Always wear heat-resistant gloves when handling the braai.
- 11. It is not advisable to completely fill the fire bowl with charcoal/briquettes as the braai may become far too hot to cook successfully (3kg bag of charcoal/briquettes in a 43cm diameter braai should last for at least two full braais).
- 12. Lightly spray flare-ups with water.
- 13. After use do not put cold water onto hot charcoal in braai rather use sand, ild cinders or water spray.

CARE & MAINTANENCE



HOW TO ORDER REPLACEMENT PARTS:

To ensure you get the correct replacement part(s) for your gas braai, refer to the parts list in the manual.

You will need the following information:

- Gas braai model number (found on the data sticker).
- Part number of the required replacement.
- Description of the replacement part.
- · Quantity needed.

To order parts, please visit our website: www.megamaster.co.za

Note: You will be responsible for shipping costs.

WARRANTY

At Megamaster, we believe in delivering lasting quality with every product. We proudly offer this warranty for the **Megamaster Traverse Portable Charcoal Braai (Model #810-0076)** to the original consumer-purchaser. Our commitment ensures that your braai is free from defects in workmanship and materials after proper assembly and normal home use, starting from the date of purchase. Megamaster's obligation is limited to repair, replacement, or depreciated value, at the option of Megamaster.



REGISTER & ACTIVATE YOUR MANUFACTURER'S WARRANTY

Activate your manufacturer's warranty for confirmation of ownership and future product support.



How to register your product:

- Scan QR code with your mobile camera or visit megamaster.co.za
- Enter unique product code below:

INFERNO SPGB

WARRANTY

REGISTRATION CODE

CLAIM YOUR EXCLUSIVE ONLINE OFFER

Get your COUPON after registration and claim your exclusive offer on selected accessories to enjoy more braais more often.

2 PROOF OF PURCHASE

The manufacturer requires reasonable proof of the original purchase date for any warranty claims. It is essential that you retain your sales receipt and/or invoice as evidence of purchase.

If the product was received as a gift, we kindly ask that the gift giver submit the proof of purchase on your behalf.

Defective or missing parts for this limited warranty will not be replaced without registration or proof of purchase.

The manufacturer may request photographic evidence of damage.



16

CONTACT INFORMATION

Tel: +27 (12) 802 1515, CAT Monday - Thursday: 07:30 - 17:00 Friday: 07:30 - 14:00

Email: info@megamaster.co.za Website: www.megamaster.co.za

(3) RETURNING DEFECTIVE PARTS

For claims, you may be asked to return defective parts. Under this limited warranty parts required to complete such repair or replacement shall be free of charge to you except for all shipping costs for the return, which are your responsibility (prepaid by you), for inspection.

Manufacturer's will repair or replace the parts which are proven defective only during the applicable warranty period from the original date of purchase.

Manufacturer's liability is limited to repairing or replacing defective parts. Manufacturer is not liable for indirect damages, commercial use, or failure due to improper care.

No coverage for shipping, reinstallation, or service calls.

IMPORTANT NOTE

Warranty applies only to the original purchaser and is non-transferable. If original parts are unavailable, a similar replacement will be sent.

(4) WARRANTY PERIODS



1 YEAR (LIMITED) EXCLUDES DROPS, CHIPS, SCRATCHES, OR SURFACE DAMAGE.



 $\,$ 6 Months (Limited) excludes cosmetic issues like rust, scratches, and $\,$ corrosion.



1 YEAR (LIMITED) EXCLUDES COSMETIC ISSUES LIKE RUST, SCRATCHES, AND CORROSION.

5 WARRANTY EXCLUSIONS

· Cosmetic Damage:

- Scratches, dents, discoloration, and surface rust (including stainless steel parts) are not covered.
- Damage caused by abrasive cleaners or tools is not covered.

· Accidents & Misuse:

- Damage resulting from accidents, alteration, or misuse of the product is not covered.

· Environmental Factors:

- Damage caused by acts of God (e.g., fire, flood, inclement weather) is not covered.
- Tampering by animals or damage from hostile environments is not covered.

Improper Installation:

 If the product is improperly installed or not in accordance with the manufacturer's guidelines, it voids the warranty.

· Lack of Maintenance:

 Damage caused by failure to maintain and clean the product regularly is not covered.

Food Loss or Personal Damage:

 Loss of food due to product failure and personal injury or property damage are not covered under the warranty

• Other Specific Exclusions:

- Shipping charges for parts under warranty are the responsibility of the consumer.
- Service calls, repairs from unauthorized modifications, reinstallation, or transportation are not covered.
- The warranty does not apply if the product is used for commercial purposes or outside of residential use.

· Manufacturer will not pay for:

- Repairs when your product is used for other than normal, single-family household or residential use
- Service calls to your home.
- Replacement parts or repair labor costs for units operated outside South Africa.
- Pickup and delivery of your product.
- Postage fees or photo processing fees for photos sent in as documentation.
- Repairs to parts or systems resulting from unauthorised modifications made to the product.
- The removal / reinstallation of your product.
- Shipping cost, standard or expedited, for warranty/non warranty and replacement parts.

DISCLAIMER OF IMPLIED WARRANTIES & LIMITATION OF REMEDIES

- Repair or replacement of defective parts is the only remedy under this warranty.
- · This warranty is the sole express warranty; no other product specifications or warranties are implied.
- Manufacturer's liability is limited to the purchase price.
- · Warranty applies only to products bought from authorised retailers.



CONTACT INFORMATION

Tel: +27 (12) 802 1515, CAT

Monday - Thursday: 07:30 - 17:00

Friday: 07:30 - 14:00

Email: info@megamaster.co.za

Website: www.megamaster.co.za

