

ASSEMBLY INSTRUCTION



ax1



bx4






cx16



dx4












fx1



SKU:23481/23483/23485/23487/23489

ASSEMBLY INSTRUCTION

 ax1	
 bx4	
 cx16	
 dx4	
 fx1	



SKU:23482/23484/23486/23488/23490