

tala

Installation Guide TRIPLE PENDANT

Thoughtful lighting, responsibly designed in London.

Thank you for making the switch to Tala. Discover the full Tala family at us.tala.co.uk

BEFORE STARTING

We advise the fitting of our canopy and pendants to be performed by a qualified electrician. Please read through these instructions before commencing work, and keep them for future reference. Please take extreme care when carrying out these instructions.

IMPORTANT

This light fitting must be connected to the supply earth. If your lighting circuit does not have an earth, ask a qualified electrician to provide an earth facility. This light fitting is suitable for indoor use only. This fitting operates on 120V mains voltage. Please visit our website to see our recommended dimmers.

WARNING

Always switch off electricity supply at the mains during installation and maintenance. We recommend that the fuse is withdrawn or the circuit breaker is switched off whilst work is in progress. Do not just turn off at the wall switch. All fittings must be installed in accordance with current NFPA 70, National Electrical Code (NEC).

RECOMMENDED EQUIPMENT

- Small flat head screwdriver
- Wire strippers
- Insulation tape
- M10 (17mm) (5/8IN) wrench or Adjustable wrench Further equipment may be required for fixing to your ceiling.

FOR INDOOR USE ONLY

SKU - CP-WHT-SML-WP-01-US

SKU - CP-WHT-SML-OP-01-US

SKU - CP-WHT-SML-GP-01-US SKU - CP-WHT-SML-BP-01-US

SKU - CP-BLK-SML-GP-01-US

SKU - CP-BLK-SML-BP-01-US

SKU - CP-BLK-SML-WP-01-US

SKU - CP-BLK-SML-OP-01-US












Scan me for more


Intertek 5018709


Triple Pendant - Provided Components













STEP 5 Connect the pendants, plate and mains wiring as shown. Junction boxes not included Mains supply Earth tag from ceiling bracket Earth tag from B ceiling plate Household Earth \bigoplus Brown or Red (L) White (N) -Pendants **Pendants** Blue or Black or Red (L) Black (N) **Pendants**






PENDANT DISPLAY GUIDE

ADJUSTING THE CORD

To adjust the cord to your desired length, using a flat head screw driver, loosen the grub/set screw (1) and push the cable up into the ceiling plate.

Secure the cable in place by re-tightening the grub screw.

Maintain all double insulation.



MINIMUM CORD LENGTH (A)




For all bulbs shortest recommended cord length is 14 in


DISTANCE BETWEEN PENDANTS (B)





Recommended minimum distance between pendant, dependant on bulb style, are as follows:


Voronoi I - 6 in Voronoi II - 8 in Voronoi III - 14 in Sphere IV - 6 in All other bulbs - 4 in











WARRANTY AND AFTER-CARE

This product has a two-year warranty. If there appears to be a functional defect with the product during this time, please contact our team at customerservice@tala.co.uk.

Please note, the flexible cable attached to this luminaire cannot be replaced; if the cable is damaged, recycle the luminaire and seek a replacement.

Join the Community