



Follow us:    

5900 Parretta Drive, Kansas City, MO 64120

Features and specifications subject to change without notice.  
Visit [midlandusa.com](http://midlandusa.com) for more information on genuine Midland  
accessories (not included) for all Midland MicroMobile® products.

©2022 Midland Radio Corporation. All Rights Reserved.










# QUICK START GUIDE

MXT105B



# QUICK START

1. PLUG THE DC POWER INTO THE VEHICLE'S CIGARETTE LIGHTER
2. PLUG THE DC CONNECTOR INTO THE DC JACK 
3. ATTACH ANTENNA CONNECTOR TO ANTENNA JACK 
4. PLACE THE ANTENNA AT THE HIGHEST POINT OF THE VEHICLE
5. PRESS AND HOLD  FOR 2 SECONDS
6. PRESS THE  TO ADJUST THE VOLUME
7. PRESS THE  TO SELECT THE CHANNEL
8. LONG PRESS THE  TO ACTIVATE THE WEATHER SCAN
9. TO POWER OFF, PRESS & HOLD  FOR 2 SECONDS

