

GLUE RENEW

AN EASY WAY TO RECONDITION G3 CLIMBING SKINS

- Reconditions old adhesives
- Suitable for all G3 skins
- G3 factory formulation
- Ultra-low temperature tolerant adhesive
- Manageable at very low temperatures

CONTENTS OF GLUE RENEW PACKAGE:

2 lengths of glue renew product Re-gluing instructions







AN EASY WAY TO RECONDITION G3 CLIMBING SKINS

Scan the QR code for video instructions, product information and more.

EQUIPMENT YOU WILL NEED:

Work bench or surface Heat gun Waxing iron or household iron (no steam) - adjustable to 180°C Metal paint scraper or metal spatula Newspaper and cardboard Utility knife Clamps (2) (to hold skin to work bench)

Use only to renew or refresh G3 climbing skins. Do not use with a non-G3 climbing skins due to chemical incompatibility amongst different climbing skins.

DIRECTIONS FOR REMOVING OLD ADHESIVE

Thoroughly remove old or contaminated climbing skin adhesive before applying G3 Glue Renew. G3 recommends the following method:

- 1. Lay climbing skin adhesive side up on the workbench and clamp taut at both ends.
- 2. If you have a heat gun, remove the old adhesive by moderately heating and scraping the adhesive onto a piece of cardboard. Skip to step 5.
- 3. If you don't have a heat gun, cover the climbing skin adhesive with 30cm long sections of newspaper. Heat the newspaper sections at medium temp, ~160°C, by slowing passing over it with the waxing iron.
- 4. Immediately after heating, scrape the adhesive and newspaper off the climbing skin with your metal paint scraper.
- 5. Repeat process until no adhesive remains on the surface of the climbing skin. Discard old adhesive.

DIRECTIONS FOR APPLYING THE NEW ADHESIVE:

- 1. Peel back the Glue Renew plastic liner (transparent side) to expose the adhesive. Place the Glue Renew adhesive side down on the freshly scraped climbing skin. Use a utility knife to cut to the desired length and width, take care not to cut the climbing skin underneath.
- 2. Iron Glue Renew onto the climbing skin fabric at medium temp, ~160°C. Work from tip to tail applying medium pressure and moving slowly down the climbing skin to evenly apply the adhesive. The pressure should be enough to even out the surface without the adhesive seeping out the sides. Repeat motion until the paper backing appears smoother and darker. The adhesive may have small wrinkles and air bubbles, work in sections applying higher pressure for 2-3 seconds to even out these areas.
- 3. At higher temp, ~180°C, quickly pass over the adhesive surface and edges with light-medium pressure.
- 4. Trim any excess adhesive using a knife and allow the adhesive to settle. For best results, G3 recommends waiting 16-24hrs before removing the release paper.
- 5. When you are ready to remove the release paper, start by peeling back about an inch of paper at the climbing skin tip in one continuous piece.
- 6. Flip the climbing skin so the plush is facing up and hold edge of the paper liner down with your palm while slowly pulling the climbing skin away from the paper. If the paper rips, slowly peel at a 45° angle until it is a continuous piece again.

G3 PRO TIPS:

If the Glue Renew isn't fully embedded into the backing, cover the area with a piece of parchment paper and re-apply the Glue Renew at ~180°C with high pressure. Allow the area to cool to room temperature and carefully remove the parchment paper.

Excess glue can be cleaned off tools and surfaces by heating and scraping, using citrus base cleaner, or by using an extra piece of Glue Renew to "pick up" glue.

Remaining G3 Glue Renew can be used as touch up adhesive, if required.



Printed with vegetable-based inks

on 100% recyclable materials