

Removing the keyway on Genuine Land Rover Switches

The keyway is a strip of plastic moulded onto the side of the switch, it's different on each variation of switch. The purpose was solely so that workers on the production line at the Land Rover factory knew which switch to put in each hole, as each switch was 'keyed' to only fit in one hole within the dashboard.



Removing the keyway allows any switch to be fitted into any of the switch holes.

To remove the keyway use a craft knife to 'slice' off the plastic until you have a smooth surface.

