



TO OPEN / LOCK DRAWER:

THE DRAWER WILL ARRIVE LOCKED WITH THE KEYS INSIDE A SEPARATE SEALED BAG

1. PLACE DRAWER ON COUNTER
2. DO NOT PULL TO OPEN
3. USE KEYS TO UNLOCK DRAWER, TURN ANTI-CLOCKWISE UNTIL HORIZONTAL
4. TO FULLY LOCK DRAWER, TURN KEY CLOCKWISE UNTIL HORIZONTAL

TO USE AS AN OVER COUNTER FIXED DRAWER:

1. OPEN DRAWER
2. REMOVE INNER TRAY
3. REMOVE DRAWER FROM COVER BY FULLY EXTENDING DRAWER AND TILTING DRAWER UPWARDS
4. REMOVE RUBBER FEET FROM BASE OF COVER
5. PLACE IN REQUIRED POSITION AND SCREW THROUGH INTO COUNTER
6. REPLACE DRAWER AND TRAY

TO USE AS AN UNDER-COUNTER DRAWER:

1. OPEN DRAWER
2. REMOVE INNER TRAY
3. REMOVE DRAWER FROM COVER BY FULLY EXTENDING DRAWER AND TILTING DRAWER UPWARDS
4. PLACE IN REQUIRED POSITION AND SCREW THROUGH INTO COUNTER
5. REPLACE DRAWER AND TRAY

TO CLOSE DRAWER

1. PRESS DRAWER HOME UNTIL TOUCH LATCH ENGAGES
2. TO LOCK DRAWER, PRESS FULLY HOME AND THEN TURN KEY CLOCKWISE UNTIL HORIZONTAL

KEY NUMBER BOX: