

High Temp Probe Rings

Operating Instructions

Always install probe rings starting from the probe. Installing them over the probe jack will cause them to stretch and loosen.

First Probe Ring (installed near probe jack):



Step 1: Holding the first of the two matching probe rings, slide probe ring over the probe.



Step 2: Roll probe ring over the metal springs of the high temp probe transition.



Step 3: Slide probe ring down the cable until it is over the metal springs of the probe jack. There should be slight tension to hold the probe ring in place.

Second Probe Ring (installed over high temp probe transition):



Step 1: Holding the second of the two matching probe rings, slide probe ring over the probe.



Step 2: Roll probe ring over the metal springs of the high temp probe transition.



Step 3: Position probe ring where the metal spring reduces. There should be slight tension to hold the probe ring in place.

