


Maya Wall Planter Installation Instructions



*** The Maya Wall Planter can hold a maximum weight of 5kg of evenly distributed weight when properly mounted on the wall. ***

1. Identify if there are any hidden pipes or electrical cables in the wall to avoid causing damage or risk of electrical shock during installation. Make a mark on the wall about **5cm** higher than where you require the top of the wooden hoop to hang from (A). **The wall must be capable of supporting the weight of the Maya Wall Planter when fully loaded (Approx 6kg)**. Determine the fixing method appropriate to the wall structure (e.g. plaster board plugs for a 4mm screw). If attaching to a wooden surface, no additional fixings are required but a pilot hole must be drilled. We would always recommend finding joists if possible.
2. Loop the leather strap around the top of the hoop of the planter and push the cap head screw (B) through the pre-punched holes in the leather. Using a flat/slotted head screwdriver, screw the leather strap to the wall with the cap head screw provided. Over-tightening the screw could result in the screw pulling through the leather. *When resting the planter against the wall, be very careful to avoid letting the planter swing back into the wall surface as this may damage the ceramic bowl.*
3. Screw the brushed brass cap onto the cap head screw (C). Adjust the planter ensuring the leather strap is centrally aligned to the hoop and the bowl is completely level to complete installation.

- Caring for the earthenware bowl

We have designed a set of striking earthenware bowls for our Green Range, featuring a hard-wearing glaze on the inside and a unique matte glaze on the outside, known as Engobe. We suggest you clean both the interior and exterior surface of the pot by gently wiping away any marks using warm soapy water and a lint free cloth. Once the pot is clean, gently dab dry using a soft, lint free cloth or towel. Any fibres on a cleaning cloth will stick to the outside surface more easily due to its beautiful finish.

- Caring for the wooden structure

Dust the planter with a soft, dry, lint free cloth. Mild furniture polishes can be used on the wood. The bowl can be easily removed from its wooden holder before planting. If watering plants in place, simply wipe away any surface moisture or water straight afterwards to minimise the chance of water stains.

- Caring for your plants

Always refer to the care guides and planting guidelines supplied with any plant or seed you've chosen. The Green Range earthenware pots do not have drainage holes in the base, therefore suitable drainage must be added. The bowls should be placed inside a rolled towel to stop them moving whilst planting.