

- Caring for the earthenware bowl

We have designed a striking pair of earthenware bowls for our Green Range featuring a hard-wearing glaze on the inside and a unique matte glaze on the outside, known as Engobe. We suggest you clean both the interior and exterior surface of the pot by gently wiping away any marks using warm soapy water and a lint free cloth. Once the pot is clean, gently dab dry using a soft, lint free cloth or towel. Any fibres on a cleaning cloth will stick to the outside surface more easily due to its beautiful finish.

- Caring for the wooden structure

Dust the Merryn planter with a soft, dry, lint free cloth. Mild furniture polishes can be used on the wood. The bowl can be easily removed from its wooden holder before planting. When watering the plant in place, simply wipe away any surface moisture or water straight afterwards to minimise the chance of water stains.

- Caring for your plants

Always refer to the care guides and planting guidelines supplied with any plant or seed you've chosen. The Green Range earthenware pots do not have drainage holes in the base, therefore suitable drainage must be added. The bowls should be placed inside a rolled towel to stop them moving whilst planting.