
IMPORTANT

If you are fitting this camera in conjunction with the Stinger H10 the only connection you need to make is the RCA cable. The Stinger H10 takes it's reverse trigger via the vehicles OBD so you do not need to connect the red or black wires.



MUD Piggy Back Loom

If you are using the MUD Piggy Back Loom follow the following instructions;

Plug the MUD Piggy Back loom into the Reverse Lamp loom.



You will now need to route the RCA cable down the length of the vehicle. You will notice the fly leads on the RCA cable that need connecting to the fly leads on the piggy back loom are at the end of the RCA cable which is connected into your head-unit. You will therefore need to extend the red and black fly leads from the piggy back loom to the front of the vehicle to connect into the +VE (red) and -VE (black) wires this provides the trigger for the camera.