



River Table Installation Instructions



Due to the nature of steam bent wood and the unique qualities of this individually hand crafted design, the steam bent curves of the River Table may cause a slight difference in height between each of the brass mounting points. Because of this, the legs on the River Table are height adjustable, helping to ensure the glass top is flat and fully supported. Rotate each of the brass legs (A) as needed onto the threaded bar (B) underneath the wooden bends of the table to make sure the glass is completely level. There should be no gap between the brass mountings and the wooden bends (C).

The River Table can support upto 15kg of evenly distributed weight, however the areas circled above can only support a maximum of 4.5kgs each when not counterbalanced on the opposite side. Where possible, try to spread the weight evenly or keep the load along the centre line of the table.