

LIMITED WARRANTY (United States and Canada)

Subject to the exclusions set forth below, Midland Radio Corporation will repair or replace at its option without charge, any Midland SPK 100 which fails due to a defect in material or workmanship within One Year following the initial consumer purchase. This warranty does not apply to abuse or misuse of unauthorized accessories, unauthorized service or modification, or altered products. Accessories have a 90-day warranty from date of purchase, including any charge cables, headsets, or batteries. This warranty does not include the cost of labor for removal or re-installation of the product in a vehicle or other mounting.

ANY IMPLIED WARRANTIES, INCLUDING, WITHOUT LIMITATION THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, SHALL BE LIMITED AS SET FORTH HEREIN AND TO THE DURATION OF THE LIMITED WARRANTY, OTHERWISE THE REPAIR OR REPLACEMENT AS PROVIDED UNDER THIS EXPRESS LIMITED WARRANTY IS THE EXCLUSIVE REMEDY OF THE CONSUMER AND IS PROVIDED IN LIEU OF ALL OTHER WARRANTIES, EXPRESS OR IMPLIED. IN NO EVENT SHALL MIDLAND BE LIABLE, WHETHER IN CONTRACT OR TORT (INCLUDING BUT NOT LIMITED TO NEGLIGENCE, GROSS NEGLIGENCE, BODILY INJURY, PROPERTY DAMAGE AND DEATH) FOR DAMAGES IN EXCESS OF THE PURCHASE PRICE OF THE PRODUCT OR ACCESSORY, OR FOR ANY INDIRECT, INCIDENTAL, SPECIAL OR CONSEQUENTIAL DAMAGES OF ANY KIND, OR LOSS OF REVENUE OR PROFITS, LOSS OF BUSINESS, LOSS OF INFORMATION OR DATA OR OTHER FINANCIAL LOSS ARISING OUT OF OR IN CONNECTION WITH THE ABILITY OR INABILITY TO USE THE PRODUCTS OR ACCESSORIES TO THE FULL EXTENT THESE DAMAGES MAY BE DISCLAIMED BY LAW.

This warranty gives you specific legal rights, and you may also have other rights, which vary from state to state.

To register your product for a warranty claim, please visit <https://midlandusa.com/apps/product-registration> and contact Customer Experience at support@midlandradio.com for any additional assistance.

For Product Purchased in the USA: Performance of any obligation under this warranty may be obtained by returning the warranted product, prepaid freight, along with proof of purchase to:

**Midland Radio Corporation
Warranty Service Department
5900 Parretta Drive
Kansas City, MO 64120**

For Product Purchased in Canada: Performance of any obligation under this warranty may be obtained by returning the warranted product, along with proof of purchase to your place of purchase in Canada. This warranty gives you specified legal rights. Additional warranty rights may be provided by law in some areas within Canada.

Note: The above warranty applies only to merchandise purchased in the United States of America or any of the territories or possessions thereof, or from a U.S. Military exchange.

**20 WATT PASSIVE EXTERNAL SPEAKER**

SPECIFICATIONS

Nominal Impedance: 8 Ohms

Input Power: 10 W continuous, 20 W peak

Operating Temperature Range: -22 °F to +140 °F

Ingress Protection Rating: IP67

Input Connector: 3.5 mm mono

Input Cable Length: 6.5 ft

Speaker Size: 4 in

Housing Size (H x W x D): 5 1/8 in x 5 1/16 in x 4 in

Weight: 2 lbs

INSTALLATION

1. Choose a suitable location and surface for mounting the speaker. Keep in mind the cable will generally connect to the back of the radio and the supplied cable length is 6.5 feet.

CAUTION:

- a. Avoid mounting in direct sunlight or high-temperature areas.
 - b. Avoid mounting in areas that block air vents, including air conditioning or heating vents.
 - c. Avoid airbag deployment zones to ensure proper performance and to prevent injury.
2. Use the two to four supplied tapping screws to mount the speaker bracket to the mounting surface. The speaker weighs two lbs. and should be mounted securely. The supplied flat speed nuts can be used on the backside of the mounting surface to help secure the bracket.
 3. Route the input cable from the bracket to the back of the radio and connect the SPK100 audio input plug to the radio's 3.5mm external speaker jack.
 4. Mount the speaker to the mounting bracket with the two supplied mounting knobs. Pivot the speaker to your desired angle before tightening the knobs.
 5. Turn on the radio and test the speaker. The radio's monitor function may be toggled on as a noise source.

Note: Connecting the external speaker will generally disconnect the internal radio speaker. Radios with multiple speaker selections such as the MXT275 and MXT575, need to have the base speaker enabled for the external speaker to function.

Midland Radio Corporation

5900 Parretta Drive

Kansas City, Missouri 64120

Phone: (816) 241-8500

Fax: (816) 241-5713

E-mail: mail@midlandradio.com

midlandusa.com

