

Spire and Elin Table Light Installation Instructions




Diagram 1




Diagram 2

Ensure the electrical supply is turned OFF at the fuse board.

1. Diagram 1 shows how the Spire and Elin Wall Lights are directional and can be adjusted both up and down (A) and side to side (B). The height of the bulb holder can be adjusted by unscrewing the brass collar (C) and sliding the fitting down the wooden pole.
2. *If you have a Spire Table Light which includes a small lampshade, before screwing in your chosen light bulb, attach the shade to the bulbholder as detailed in diagram 2 above.*
3. Screw in your chosen light bulb. The light has been designed to work with an E27 **LED** light bulb, up to a maximum of **25 Watts**.
4. Turn on the power supply to complete installation.

*** If the external flexible cable or cord of this luminaire is damaged, it shall be exclusively replaced by the manufacturer or his service agent or a similar qualified person in order to avoid a hazard. ***

For more information on the installation of your product: contact@tomraffield.com +44 (0)1326 722725