

# How to set combination

- 1 This lock is preset to open with the code 0-0-0-0.
  - 2 Set the combination dials to 0-0-0-0 and withdraw the cable.
  - 3 Turn the knob 90° clockwise.
  - 4 Reset the combination dials to your desired combination code, making sure the numbers line up with the indicators on the case.
  - 5 Once you have selected your combination, turn the knob 90° counterclockwise, bringing it back to its original position.
- To change combination, repeat above steps with new combination.

