

retrospec®

Chatham **REV** 2

Electric Beach Cruiser Bike - 500W



Quick Start Guide

Quick Start Guide

Step 1: Fully charge battery


The battery will come on the bike. You can either charge it in place or remove it from the bike. Plug the provided charger into the battery and then plug the charger into the outlet.



When the battery is fully charged (green light on charger), remove the charger and install the battery into the bike or cover the charging port if left on the bike.


Step 2: Turning the bike on

1. Straddle the bike with both feet on the ground.
2. Now press and hold the power button for three seconds. This will bring the bike to life.



Step 3: Setting your pedal assist level (PAS)

Using the + and - buttons to select your desired level of assist. **NOTE:** that throttle is always available. The level will show in the red box highlighted on the display graphic below.




Step 4: Starting from a stop

Before placing your foot on a pedal, use your right hand to grab the rear brake. Then place your foot on the pedal, push forward while releasing the brake at the same time.




Step 5: Turning lights on/off

If you want the lights on, both front and rear are turned on at the light itself by a switch on the body of the tail light and head light.



Step 6. Turning the bike off

When you are done with your ride, press and hold the power button for three seconds. This will turn your bike off.





Contact Us



Need some help with your new gear? Just want to say “hey” and talk to someone on our team? We’re here for that too.
team@retrospec.com

Give us a follow, while you’re at it:

Instagram: [@retrospec](#)

[#retrospec](#)

[#readytooutdoor](#)



Making
nature
second
nature.