

ST-III F Transmitter (For Fujifilm) Firmware Instructions

1. Please update the firmware with PIXAPRO firmware update software G2. G2 can be downloaded from the essentialphoto website.

2. To check your current firmware version, switch the ST-III Trigger off, then press and hold the “MODE” button whilst switching the receiver on, and the firmware update version (e.g. Version 2.0 will read U-2.0) will be displayed on the LCD panel.

Version	Update Comment	Release Date
V07	1. To optimize the communication between the same cameras.	09/11/2020
V06	1. To improve the flash reliability.	06/12/2018
V05	1. To add the Fn-12 C.Fn custom setting so that the customer can set RF ID value.	10/01/2018
V04	1. To solve the problem that CITI600 Manual cannot be correctly triggered when all groups are set to M mode. 2. In Multi mode, press the camera shutter to determine the flash times.	18/12/2017
V03	1. To add the support of FUJIFILM GFX 50s camera. 2. To add C.Fn custom settings. The transmitter's parameters that set by Go-dox APP are not changed. And the transmitter is only for triggering. 3. To add the support of X100F, X100T cameras. Reach to 1/1250s high-speed sync in shutter (all unclosed groups must be set to M mode). 4. To solve the problem that when the Li-ion580II M are set as receivers, flashes cannot be triggered in high-speed mode (all unclosed groups must be set to M mode).	19/08/2017
V02	1. Original Firmware Version	10/07/2017

Note: For more information, please download the latest version of the instruction manual from:
www.essentialphoto.co.uk/firmware/