

ST-III Plus Trigger Canon - Firmware Instructions

1. Please update the firmware with PIXAPRO firmware update software G3. G3 can be downloaded from the [essentialphoto](http://essentialphoto.co.uk) website.

2. Firmware Version Checking: Switch the flash on, then press the "MENU" button and enter C.Fn custom functions. The firmware update version (e.g. Ver X.X) will be displayed on the LCD panel.

Version	Update Comment	Release Date
V1.4	1. To match the update of Godox flash APP.	30/06/2022
V1.3	1. To Fix Compatibility issues with Canon R5 camera . (The camera's firmware needs to be updated to Vserion V1.50).	14/02/2022
V1.2	1. To add the support of 90D camera. 2. When controlling the ST-III Plus transmitter via the smartphone in APP mode, the rectified parameters will be sent to the receiver end. 3. When restoring the factory settings, the Bluetooth password will be set to its initial value of "000000".	07/11/20
V1.1	1. To solve the problem that when setting the shutter to high speed sync and shooting continuously in 1Dx and 1DxII cameras, the shutter sometimes will return to low speed. 2. To solve the problem that when ISO is set to auto in EOS R camera, it will be turned to ISO100. 3. Double click the group button, and the corresponding groupcan be turned on /off	22/10/2019

Note: For more information, please download the latest version of the instruction manual from:
www.essentialphoto.co.uk/firmware/