

## ST-III Plus Trigger Nikon - Firmware Instructions

1. Please update the firmware with PIXAPRO firmware update software G3. G3 can be downloaded from the [essentialphoto](http://essentialphoto.com) website.

2. Firmware Version Checking: Switch the flash on, then press the "MENU" button and enter C.Fn custom functions. The firmware update version (e.g. Ver X.X) will be displayed on the LCD panel.

Version	Update Comment	Release Date
V1.2	1. To match the update of the GODOX Flash App	30/06/2022
V1.1	1. To add the support for D780 camera (original overhead light mounted on top of ST-III+ T-N) 2. To add the support for Z7 II/Z6 II camera.	31/03/2022
V1.0	3. Original Firmware	

Note: For more information, please download the latest version of the instruction manual from:  
[www.essentialphoto.co.uk/firmware/](http://www.essentialphoto.co.uk/firmware/)