

SD150R-Firmware Instructions

1. Please download the firmware file, and copy it to your USB Drive (Please ensure that there is only one bin file in the root directory). The firmware can be downloaded from the essentialphoto website.

2. Plug in the USB Drive that has the firmware file whilst your light is switched off. Turn on the light to enter the update interface. Once the upgrade is complete, it will automatically revert back to its normal interface. You can now remove your USB drive.

| Version | Update Comment | Release Date |
|---------|---|--------------|
| V1.02 | 1. Optimises switching between modes so that it feels more natural | 05/07/2021 |
| V1.2 | 1. Upgrade the GM regulation function | 08/03/2021 |
| | | |
| V1.1 | 1. To solve the problem that current is too large when first power-on. 2. Upgrade the GM function. | 01/02/2020 |