

Li-ion580 II S - TTL Speedlite (Sony) Firmware Instructions

1. Please update the firmware with PIXAPRO firmware update software G1. G1 can be downloaded from the essentialphoto website.

2. Switch the flash on, then press the “Zm/C.Fn” button for 2 seconds and enter C.Fn custom functions. The firmware update version (e.g. Ver X.X) will be displayed on the LCD panel.

Version	Update Comment	Release Date
V1.7	1. To add Pentax compatibility with the Pixapro Wireless ONE system	24/10/2018
V1.6	2. To add the option of wireless ID (C.Fn-ID); 3. To add the ON/OFF option of SLAVE mode indicator (C.Fn-Sv LED); 4. To add the function that the flash can be triggered by pressing the TEST button when being attached to camera.	01/12/2017
V1.5	1. Compatible with PIXAPRO Wireless Olympus/Panasonic 2.4GHz ECO system and Fuji 2.4GHz ECO system	24/06/2017
V1.4	1. Compatible with ST-III-C (for Canon) and ST-III-N (for Nikon) trigger. 2. To repair the Auto-off function in the wireless SLAVE mode.	08/12/2016
V1.3	1. To solve the problems occurred on RX10 camera, i.e., the shutter speed cannot be faster than 1/1000 when using radio transmission (2.4G).	08/06/2016
V1.2	1. Adjust the High-Speed Sync function: adding SYNC button to control high-speed sync function. 2. To solve the problem that the cameras flash cannot achieve high-speed sync flash when attaching to ST-III-S. 3. Optimize the agreement with SONY camera hot shoe.	25/05/2016