

GIO1 P - Round-Head TTL Speedlite (Pentax) Firmware Instructions

1. Please update the firmware with PIXAPRO firmware update software G3. G3 can be downloaded from the essentialphoto website.
2. To Check your current firmware version, press the "MENU" button and enter C.Fn menu after turning the speedlite. The firmware version (e.g. Version xx will read U xx) will be displayed on the LCD screen.

Version	Update Comment	Release Date
V1.2	1. To add the lock function by pressing the MODE button for 2 seconds. 2. To replace the display sign Slave with RX	04/09/2020
V1.1	1. To improve the heat protection system.	23/09/2019