

# PIXAPRO 70x100CM FLOOR SOFTBOX ASSEMBLY INSTRUCTIONS.

## Box Content



The 70x100cm Floor Softbox contains four rods (1x short, with a spigot, 1x medium, and 2x long), the main softbox body, which pops open like a reflector, and a round bag for the softbox main body.

## Step 1.



First, remove the winged-screw from Rod S1 and then connect it to Rod S2 to form a T-Shape

## Step 2.



Now remove the winged screws from both ends of the T-Shape, then attach an S3 rod at either the of the T-Shape to form an H-Shape.

## Step 4.



Now that the supporting frame is complete, open out the main body of the floor softbox then lift the top panel from the back ready to install the supporting frame.

# ASSEMBLY INSTRUCTIONS

## Step 5.



Use the four clips located at either end of the supporting frame, to hold the main body of the Floor Softbox open.

## Step 6.



Now that the Floor Softbox is complete, all that is left to do is mount your flash to the spigot on the supporting frame, place the flash head through the opening at the back, and pull the drawstring to prevent light leakage

## The Floor Softbox is Now Complete.



The PIXAPRO 70x100cm Floor Softbox is now ready for use.

### 70x100cm Floor Softbox Assembly Video



EssentialPhoto  
**PIXAPRO**<sup>®</sup>

PIXAPRO LTD.  
50 Popes Lane, Oldbury, West Midlands, B69 4PA  
Tel: 0121 552 3113  
Company Registration No. 07601334  
Web: [www.essentialphoto.co.uk](http://www.essentialphoto.co.uk)  
E-mail: [customerservice@essentialphoto.co.uk](mailto:customerservice@essentialphoto.co.uk)

Facebook: [www.facebook.com/EssentialPhoto.UK](http://www.facebook.com/EssentialPhoto.UK)

Twitter: [www.twitter.com/EssentialPhoto\\_](http://www.twitter.com/EssentialPhoto_)