

PIXAPRO 75CM CUBE TENT HOW TO FOLD INSTRUCTIONS.

Step 1.



First ensure the cube tent opening is facing forwards, and then push the top-front edge of the tent in the bottom-rear edge of the tent to form an "L" Shape.

Step 3.



Hold the cube tent with one hand on one corner, and hold the corner diagonally opposite the first corner as shown.

Step 2.



Now tuck-in any excess material at the sides, then fold the cube tent down until it lays flat.

Step 4.



Rotate your hands in opposite directions to twist the cube tent into a Figure of Eight as shown.

FOLDING INSTRUCTIONS

Step 5.



Push both ends of the figure-eight together, and the tent should collapse in on itself.

Step 6.




Now place your folded cube tent back into its carrying case.

The Tent Is Now Folded



75cm Cube Tent

How to Fold Instructional Video



EssentialPhoto
PIXAPRO[®]

PIXAPRO LTD.

Unit 5 Sterling Park
Pedmore Road
Brierley Hill, West Midlands,
DY5 1TB
Tel: 0121 552 3113
Company Registration No. 07601334
Web: www.essentialphoto.co.uk
E-mail: info@essentialphoto.co.uk

Facebook: www.facebook.com/EssentialPhoto.UK

Twitter: www.twitter.com/EssentialPhoto_