

Waterproof Wireless Speaker User's Manual



B18P

Introduction:

You can use this item with tablet, notebook and many types of smartphone to stream music, and enjoy handsfree calling. In order to get the best results when using the device, please read this manual first before using.



Features

- Clear sound music with colorful light show
- Volume and song control directly on unit
- Stunning sound clarity
- Ultra portable design
- Great for parties, indoor and outdoor
- Allow you to use hands free function

Specification

Loudspeaker: 4Ω 5W
 Built-in Battery: Li-ion 1000mAh
 Dimensions: 111mm(L)*99mm(W)*54mm(H)
 SNR: ≥82dB
 Wireless Working Frequency: 2.402-2.480 GHZ
 Wireless Transmission Distance: up to 10 m
 Charging Time: 3-4 hours
 Weight: 220 g
 Speaker Dimension: 50mm
 Charging: 5 V, 1A

Package Contents



1. Bluetooth Speaker

2. USB Charging cable
And audio cable

3. User manual

Important Safety Precautions

When using your Bluetooth Mobile Speaker, basic safety precautions should always be followed, including the following:


1. Keep this product and its charging cable away from excessive heat.
2. Do not operate this device with a damaged cable or after it has malfunctioned or has been damaged in any manner.
3. Do not disassemble your device.
4. Only use your device on a flat, stable surface.

Charging your Speaker


1. Connect one end of the included USB Charging Cable to the Charging Port on your speaker. Then plug the other end of the USB Charging Cable into a suitable USB port on your computer to recharge your speaker's internal rechargeable battery.

NOTE: The internal battery of your speaker takes approximately two hours to charge when completely drained.
 2. When charging, a red LED light will illuminate to indicate that the unit is charging. The red light will turn off when your unit is fully charged.

A Quick Look at Your Device



1. Previous: Press and hold to access the last track in playlist. Press to lower the volume.
2. Next: Press and hold to access the next track in playlist. Press to increase the volume.



3. ON/OFF Switch
Press and hold the "⏻" for power on
Press and hold the "⏻" again for power off

4. Light Change
Short press this button to cycle through 5 light modes.
Under the playing music mode, you can press and hold the light button to enter the light flash with music mode.



5. Charging Port/Aux-in
You can plug one end of the included USB Charging Cable into this jack, while plugging the other end into a USB port on your computer in order to charge your speaker's built in lithium battery.

Understanding the LED Status Lights

When Charging Your Speaker

Solid red LED = Charging
 No red LED = Charge Complete

When Pairing Your Speaker to a Bluetooth Audio Source

Rapid blinking blue LED: Bluetooth not connected. (Ready to pair.)
 Solid blue LED: Bluetooth connected.

Aux-In Mode

1. Power on, the Blue LED stay illuminated.
2. Plug in the supplied 3.5mm cable into your device. The other end is connected to the unit.
3. The blue LED will blink slowly to indicated that you have entered Aux-In mode.

Pairing Bluetooth Devices to Your Speaker

In order to pair your Bluetooth audio device to your Bluetooth Speaker for the first time, follow the steps below:

- 1). Make sure your Bluetooth audio source is held within three meters of your speaker.
- 2). Press and hold the "⏻" switch on your speaker to power on. The LED light will blink blue to indicate that you have entered pairing status.
- 3). Go to the Bluetooth Manager of your Bluetooth audio source. Please refer to the User's Manual of your Bluetooth audio source for more information.
- 4). Search Bluetooth devices and select "B18P".
- 5). Once paired, the blue LED light will be solid and you can use your speaker to listen to audio from you Bluetooth sound source.

NOTE: Press the "⏻" twice to disconnect the Bluetooth

Using the Hands-Free Function

When an iPhone or other smartphone is connected to your speaker follow the steps below to take calls hands-free.

1. Press "⏻" to pick up the call.
2. Press and hold "⏻" to reject the call.
3. During call: Press "⏻" twice to hang up the call.

TWS function

If you have two of B18P, you can use multiple point to achieve wireless stereo combined playing music.

1. Make sure two B18P are without any Bluetooth connection.
2. Power on both units and press "⏻" button on the speaker, the two speakers will connect automatically with indicated tone. When blue LED blink quickly on the one unit and solid on the other one, it means the multiple point connection is successful.
3. Under connection, search Bluetooth device and select "B18P"
4. When the device and the units are connected, the blue LED of both units will be solid.
5. Press the "⏻" button twice to disconnect the TWS connection from the units.
6. Press the "⏻" button twice again to disconnect the device from the unit.

Troubleshooting

Problem	Solution
The speaker doesn't connect to device	Speaker needs to be connected/re-paired to device
A tone is heard every few seconds	Speaker needs to be charged
Bluetooth connection distance cannot reach to 32ft.	Avoid operating the Bluetooth speaker in areas of strong electromagnetic interference, such as near induction cookers, large power fans, motors etc. Move the speaker closer to Bluetooth device. Fully charge the speaker and try again.
The speaker will not power on	Speaker needs to be charged
The speaker doesn't control track(s)/volume	Speaker needs to be in Bluetooth mode for full control
The speaker distorts at high volume	The devices' volume needs to be lowered

