

Waterproof Bluetooth Speaker User's Manual



B18L Speaker

Introduction:

you can use this item with tablet, notebook and many types of smartphone to stream music, and enjoy handsfree calling. In order to get the best results when using the device, please read this manual first before using.


Features

- Super waterproof and shockproof
- Clear sound music with colorful light show
- Portable magnet design
- Volume and song control directly on speaker unit
- Stunning sound clarity
- Ultra portable design
- Great for parties, indoor and outdoor
- Allow you to make and answer phone calls

Specifications

Bluetooth version: 5.0
 Loudspeaker: 4Ω 5W
 Built-in Power: Li-ion 1000mAh
 Dimensions: 102mm(L)*93mm(W)*43mm(H)
 SNR: ≥80dB
 Wireless Working Frequency: 2.402-2.480 Ghz
 Wireless Transmission Distance: up to 10m
 TWS Transmission Distance: up to 5m
 Charging Time: About 2.5 hours
 Weight: 170g
 Speaker Dimension: 45mm
 Charging: 5 V, 500mA


Package Contents



1. Bluetooth Speaker



2. USB Charging cable



3. User manual

Important Safety Precautions

When using your Bluetooth Mobile Speaker, basic safety precautions should always be followed, including the following:

1. Keep this product and its charging cable away from excessive heat.
2. Do not operate this device with a damaged cable or after it has malfunctioned or has been damaged in any manner.
3. Do not disassemble your device.
4. Only use your device on a flat, stable surface.


Charging Your Speaker

1. Connect one end of the included USB Charging Cable to the Charging Port on your speaker. Then plug the other end of the USB Charging Cable into a suitable USB port on your computer to recharge your speaker's internal rechargeable battery.

NOTE: The internal battery of your speaker takes approximately 2.5H hours to charge when completely drained.

2. When charging, a red LED light will illuminate to indicate that the unit is charging. The red light will turn off when your unit is fully charged.


A Quick Look at Your Device



1. Previous: Press and hold to access the last track in playlist. Press to lower the volume.


2. Phone: Press this button to activate the the speaker phone function. When music is playing, press to play or pause a track.

3. Next: Press and hold to access the next track in a playlist. Press to increase the volume.



4. Charging Port

You can plug one end of the included USB Charging Cable into this jack, while plugging the other end into a USB port on your computer in order to charge your speaker's built in lithium battery.



5. ON/OFF Switch

Press and hold the "⏻" for power on
 Press and hold the "⏻" again for power off

Understanding the LED Status Lights

When Charging Your Speaker
 Solid red LED = Charging
 No red LED = Charge Complete

RGB Light show

How to change the light model: Short press both the volume "⏮" and "⏭" of the speaker

Pairing Bluetooth Devices to Your Speaker

In order to pair your Bluetooth audio device to your Bluetooth Speaker for the first time, follow the steps below:

- 1). Make sure your Bluetooth audio source is held within three meters of your speaker.
- 2). Press and hold the "⏻" switch on your speaker to power on. The LED light will blink blue to indicate that you have entered pairing status.
- 3). Go to the Bluetooth Manager of your Bluetooth audio source. Please refer to the User's Manual of your Bluetooth audio source for more information.
- 4). Search Bluetooth devices and select "B18L".
- 5). Once paired, the blue LED light will be solid and you can use your speaker to listen to audio from you Bluetooth sound source.
- 6). Press and hold the "⏻" to disconnect the Bluetooth.

Using the Hands-Free Function

When an iPhone or other smartphone is connected to your speaker follow the steps below to take calls hands-free.

1. Press "⏻" to pick up the call.
2. Press and hold "⏻" for 2 sec to reject the call.
3. During a call: Press "⏻" again to hang up the call.
4. During the TWS model, only the master microphone and button can be used.

TWS Function

If you have two of B18L, you can use multiple point to achieve wireless stereo combined playing music.

1. Make sure two of B18L are without any Bluetooth connection.
2. Power on both units and press "⏻" button on the speaker, the two speakers will connect automatically with indicated tone. When blue LED blink quickly on the one unit and blink slow on the other one, it means the multiple point connection is successful.
3. Under connection, search Bluetooth device and select "B18L".
4. Hands-free Function is only available on master speaker

Troubleshooting

Problem	Solution
The speaker doesn't connect to device	Speaker needs to be connected/re-paired to device
A tone is heard every few seconds	Speaker needs to be charged
Bluetooth connection distance cannot reach to 32ft.	Avoid operating the Bluetooth speaker in areas of strong electromagnetic interference, such as near induction cookers, large power fans, motors etc. Move the speaker closer to Bluetooth device. Fully charge the speaker and try again.
The speaker will not power on	Speaker needs to be charged
The speaker doesn't control	Speaker needs to be in Bluetooth mode for full control
The speaker distorts at high volume	The devices' volume needs to be lowered