

RAINBOW LED REMOTE CONTROLLER INSTRUCTIONS

Autoplay 366 Modes

Power/Play Pause

366 Mode switching

M+: Mode +

M- : Mode -

10 Speed Levels

M+: Speed +

M- : Speed -

Monochrome Display. Press the buttons, Light strip displays its corresponding colours



In the "off" state, press this button to enter the "Set Up" menu. Then Press the M+ or M- to adjust the LED. Press the "blue" button to adjust the RGB sequence. Once complete, press "OFF" to save and exit

Shut Down
Auto-Save when shut down

Brightness adjustment (32 Levels)

RGB sequence adjustment function in the state of shutdown. Press "AUTO" to enter the setup menu. Now the first three lights of LED Strip displays the current RGB sequence. Press this button to adjust until the sequence of the previous three lights are Red Green and Blue. then press the "OFF" button to save.