

CITI600 Manual - Firmware Instructions

1. Please update the firmware with PIXAPRO firmware update software G1. G1 can be downloaded from the [essentialphoto](http://essentialphoto.co.uk) website.

2. Firmware Version Checking: Switch the flash on, then press the "MENU" button and enter C.Fn custom functions. The firmware update version (e.g. Ver X.X) will be displayed on the LCD panel.

Version	Update Comment	Release Date
V1.9	1. To add Pentax compatibility with the Pixapro Wireless ONE system	23/10/2018
V1.8	2. To add the option of wireless ID (C.Fn-ID).	07/12/2017
V1.7	1. To make it compatible with PiXAPRO wireless Olympus/Panasonic 2.4GHz system and FUJIFILM 2.4GHz system.	24/06/2017
V1.6	1. To optimize the battery management.	08/10/2016
V1.5	1. To Make it compatible with ST-III-S flash trigger (for Sony). 2. Extending the lighting time of modeling lamp (3/2/1=30/60/90 minutes).	13/04/2016

Note: For more information, please download the latest version of the instruction manual from:
www.essentialphoto.co.uk/firmware/