

ST-IV Plus L - TTL Flash Trigger (Leica) Firmware Instructions

1. Please update the firmware with PIXAPRO firmware update software G3. G3 can be downloaded from the essentialphoto website.
2. To Check your current firmware version, press the "MENU" button and enter C.Fn menu after turning the speedlite. The firmware version (e.g. Version xx will read U xx) will be displayed on the LCD screen.

Version	Update Comment	Release Date
V1.4	1. Fixing the issue of incorrect display and the inability to switch groups in the single-group setting interface, which is caused by adjusting the user's preset values.	19/07/2023
V1.3	1. To fix the occasional startup issue of the ST-IV+ - XProII-L when the battery voltage is low.	01/06/2023
V1.2	1. Optimize the power-on communication logic of the Bluetooth module.	14/04/2023
V1.1	1. To extend the Ready state for 60 minutes with the green light flashing, and then enter the sleep mode, avoiding the problem that half-pressing the shutter on the SL2 camera for the first shot misses flashes after waking up from the sleep mode.	13/09/2022

Note: For more information, please download the latest version of the instruction manual from the "Downloads" tap of the product listing on the essentialphoto.co.uk website.