

CITI600 Pro - Firmware Instructions

1. Please update the firmware with PIXAPRO firmware update software G2. G2 can be downloaded from the [essentialphoto](http://essentialphoto.co.uk) website.

2. Firmware Version Checking: Switch the flash on, then press the "MENU" button and enter C.Fn custom functions. The firmware update version (e.g. Ver X.X) will be displayed on the LCD panel.

Version	Update Comment	Release Date
V1.8	1. To add GROUP to the menu, with Controllable Receiver Groups increased to 16	15/08/2023
V1.7	1. To add compatibility with Flash Trigger for Leica --- ST-IV+L Wireless System	16/08/2022
V1.5	1. To resolve the reception problems of external wireless 2. To adjust the initialization of reset.	31/05/2019
V1.3	1. Add compatibility for PIXAPRO wireless 2.4GHz ONE system for PENTAX 2. To change the power adjustment from 1/3 stop increments to 1/10 stop increments 3. To optimise battery management and temperature protection program.	31/08/2018

Note: For more information, please download the latest version of the instruction manual from:
www.essentialphoto.co.uk/firmware/