

WIRELESS SMART MEAT THERMOMETER

MODEL: 530-04113

WARNING

- Do not expose the probe to high temperatures or direct flames.
- Do not use the probe when searing.
- The repeater is not waterproof. Do not immerse in liquids.
- Always fully insert the probe into the meat. Do not allow the probe to come into contact with hot cooking surfaces.
- Do not submerge the probe in liquid. It is water resistant, not waterproof.
- Hand-wash with soap and water.
- The probe will be very hot during and immediately after use. Do not touch. Always wear heat-resistant gloves.
- This product is not a toy. Keep away from children and store out of reach.
- Do not use in a microwave oven.
- Do not place the repeater on or near hot surfaces.



CAUTION

Consuming raw or undercooked meats, poultry, seafood, shellfish, or eggs may increase your risk of foodborne illness, especially if you have certain medical conditions.



SPECIFICATIONS

Supported Devices

iOS, Android

Repeater Battery

1000 mAh Li-ion

Charger

USB-C (5 V, 0.6 A)

Connection

Bluetooth 5.2

Refresh Frequency

1 sec

Temperature Range

-10-105°C (14-221°F)

Temperature Accuracy

0.9°F (±0.5°C)


Probe Battery

5 mAh Li-ion (2.4 V)

Probe Charge Time


1-2 hrs
(30+ hrs of use)

REPEATER/CHARGING DOCK OVERVIEW



- A Repeater Connection Status**
The signal connection strength between the repeater and the smart device
- B Repeater Battery Gauge**
- C Probe Battery Gauge**
- D Probe Temperature**
The internal meat temperature
- E Temperature Unit**
Use the Nex-fi app to change unit.
- F Backlight**
3 min auto-off when probe removed;
15 sec auto-off with probe docked

PROBE OVERVIEW



Meat Temperature Sensor
105°C (221°F) Maximum Temperature

Minimum Insert Mark
The area below this marking MUST be fully inserted for proper functionality.

Ambient Temperature Sensor
370°C (698°F) Maximum Temperature

IC Statement

This device complies with Industry Canada license-exempt RSS standard(s). Operation is subject to the following two conditions:

- (1) This device may not cause interference.
- (2) This device must accept any interference, including interference that may cause undesired operation of the device.


FCC Warning

This device complies with part 15 of FCC rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference.
- (2) This device must accept any interference, including interference that may cause undesired operation.

CONNECTING TO THE NEX-FI APP

- 1 Install the Nex-fi app onto your smart device.
- 2 Remove the probe from the repeater.
- 3 Follow screen prompts to select and add the new Nexgrill wireless meat probe.



APP FEATURES


- Use multiple wireless probes at the same time.
- Name each wireless probe for easy reference.
- Set custom or preset meat temperature targets.
- Alarm notification, if selected, when food is done.
- Monitor the battery levels of the repeater and the probe.



SCAN THIS QR CODE
TO REGISTER


CHARGING THE REPEATER

Before initial use, charge the repeater for 2 hours.



Connect the USB-C cable to the charging port on the side of the repeater.

Battery Charge Scale



NOTE: The battery icons flash while charging.

USING THE WIRELESS MEAT PROBE

1. The probe and repeater will power on once the meat probe is removed from the repeater.
2. Insert the probe into the meat. Position the tip in the middle of the meat and insert up to the depth indicator line.
3. From the Nex-fi app, set the desired target temperature or meat doneness preset.
4. When finished, wash the meat probe to remove bacteria. Dry using a cloth.
5. Place the meat probe into repeater case. After a few seconds, the repeater will turn off and the probe will start charging.

WARRANTY - 1 YEAR

This product carries a one (1) year warranty against defects in workmanship and materials. At its discretion, Nexgrill agrees to have any defective part(s) repaired or replaced free of charge, within the stated warranty period, when returned by the original purchaser with proof of purchase. This product is not guaranteed against wear or breakage due to misuse and/or abuse.