CrossWave® Cordless Max using the 3-in-1 Docking Station & Clean out Cycle | Support

The 3-in-1 Docking Station functions as a clean out tray, charging station, and storage tray for machine, brush rolls, and filter.

- Before placing machine on 3-in-1 Docking Station make sure Brush Roll Drying Tray is installed correctly, once it is securely installed it will click and sit flush on the floor



Clean out Cycle:

- Place machine on docking station
- Make sure docking station is plugged in
- Fill clean water tank with warm tap water to the clean out cycle icon on the tank
    - Put clean water tank back on machine



- Take machine off docking station
  - Wipe off any excess water on docking station



- Return machine to docking station
- Empty and clean both tanks before storing machine

Charging:

- Plug adaptor into wall outlet
- With machine on docking station, battery LED lights will illuminate white while charging
- If lights are not on, remove machine and realign on docking station
- If one light is blinking white battery is at less than 10%
- For a full charge allow machine to charge for 4 hours
    - 3 white lights indicate a fully charged battery