



## **USE & CARE GUIDE**

### **BLAZE LED GRILL LIGHT KITS**

This manual is compatible with model numbers:

BLZ-2LED-BLUE; BLZ-3PROLED-BLUE; BLZ-4B-LED-BLUE; BLZ-5LTELED-BLUE; BLZ-2LED-WHITE; BLZ-3PROLED-WHITE; BLZ-4B-LED-WHITE; BLZ-5LTELED-WHITE; BLZ-2LED-AMBER; BLZ-3PROLED-AMBER; BLZ-4B-LED-AMBER; BLZ-5LTELED-AMBER

NOTE: This grill uses a “Transformer” to provide power to the LED lights and internal lights. This diagram shows the connection to the transformer.



- **Keep any electrical supply cord and fuel supply hose away from any heated surfaces, sharp edges and dripping grease.**
- **Please disconnect the power source or ensure the power is shut off to your grill before installing the grill lights.**
- **PLEASE ALLOW GRILL TO COOL BEFORE YOU BEGIN THE INSTALLATION OF YOUR LED LIGHTS**

## **INSTALLATION INSTRUCTIONS:**

1. Slide out the grill a couple of inches to remove the control panel, but not so far that it can tip over.
2. Remove the knobs from the control panel by pulling away from face of grill.
3. Remove the two screws holding each bezel in place on the control panel.
4. Remove all bezels from the control panel.
5. Remove the two screws on each side of the grill to remove the control panel and gas manifold.
6. Remove the control panel from the grill.
7. Once removed, follow the LED assembly wire to each LED light on one side and the transformer wire to the switches on the other side.
8. Remove the old LED bulb and replace with the new LED bulb. The black and red wires slide onto the bulb connections. It does not matter which side you put the wires.
9. Re-assemble each side of the control panel and gas manifold.
10. Assemble the knob bezels with two screws holding the bezel in place on the control panel.
11. Put the knobs on the control panel.