

VESSEL SINK INSTALLATION INSTRUCTIONS




Before installing, read entire Vessel Sink Installation Instructions. Observe all local building and safety codes. We recommend consulting a professional if you are unfamiliar with this type of installation. Pelican accepts no liability for any damages to the floor, walls, plumbing, or personal injury during installation.

TOOLS AND MATERIALS:

Damp Cloth
Silicone Sealant
Thread Sealant
Basin Wrench

INSTALLATION

1. Carefully place the sink upside down on the counter with a towel or other soft cloth beneath to prevent damage. Apply a continuous bead of silicone to the base of the sink where it will rest on the counter.
2. Turn the sink right-side-up and position it back over the 2" drain hole.
3. Remove any excess silicone with a damp cloth. Let the silicone dry for 24 hours. If a lavatory drain is included, move on to the **Drain Installation** section.



DRAIN INSTALLATION

1. Disassemble the drain by removing the threaded tailpiece, rubber sealing gaskets, friction washer and lock nut from the drain body.
2. Place thread sealant on the threaded section of the tailpiece and reattach to the drain body. Slide the flat rubber sealing gasket up the tail piece to the top of the drain body. The gasket will create a watertight seal between the drain flange and sink.
3. Place the drain in the drain hole in the sink. On the underside of the counter, attach the tapered rubber gasket. With the flat side facing down, slide the gasket up the threaded shank until it makes contact with the bottom of the sink.
4. Slide the friction washer up to meet the rubber gasket. Thread the lock nut onto the threaded shank. Hand-tighten and make sure that the drain is properly aligned. When ready, finish tightening with a basin wrench to secure the drain.