
## TYPE FOUR: with side sprayer




I. Remove the Rubber washer (2), Metal (3) and lock nut (4) from the faucet.

And then put them into the deck plate(13), plastic washer(12) and


Put the base(8) into the hole.

II.Put the sprayer(6) and pull out hose(7) through the base(8).


Screw rubber washer(2), metal washer(3) and lock nut(4) onto the pipe(1) and base(8).




and cold hose (11).




## SOAP DISPENSER:




I.Screw pipe(1) on the base(8). And then put them into the hole.





IV. Add detergent to plastic bottle.



V.Push down the head of soap dispenser.



onto the pipe (1).

VI.Completed



# oun ain SERIES Kitchen Faucet

**INSTALLATION INSTRUCTIONS** 

### YOU MAYBE NEED:




Firstly, thanks for purchasing our products.


This instruction manual lists four types of kitchen faucets for reference.

There is corresponding to installation manual for your purchased products.

## TYPE ONE:



## TYPE TWO: without panel



## TYPE THREE: with panel

