

TEMPERING BY-PASS VALVE

INSTALLATION INSTRUCTIONS

The Webstone Tempering By-Pass Valve is designed for use in conjunction with the Webstone Water Heater Tempering Valve (WHTV), providing unmixed high-temperature water to select appliances. Water heater output temperature should be set appropriately for the high-temperature appliance, but not to exceed the maximum WHTV hot water input of 194°F - see WHTV installation instructions for full specifications.

IMPORTANT: Follow all federal/national, state, and local codes when installing, testing, or performing work on systems. All parts are covered by a warranty against manufacturing defects, provided they are installed by a licensed plumber and operated under normal working conditions. If you have any questions or comments, please contact us at (800) 225-9529 or visit us on the web at www.webstonevalves.com.

WARNING: Water in excess of 120° F can cause scalding, severe injury, or death.

Output from the tempering by-pass valve is suitable for direct connection to appliances or other high-temperature applications ONLY.

UNTEMPERED WATER IS NOT SUITABLE FOR DOMESTIC HOT WATER APPLICATIONS!

DO NOT connect the tempering by-pass valve to fixtures where users can come into contact with high-temperature water.

INSTALLATION


The Tempering By-Pass Valve is intended to be installed in place of the Union Fitting included with the Water Heater Tempering Valve (referenced as **D** in the WHTV instructions). Refer to the WHTV Installation Instructions for the full installation procedure.

- 1. Apply PTFE tape to water heater **G** hot outlet.
- Connect the large fixed (non-grooved) end of Tempering By-Pass Valve to the water heater hot outlet.
- Insert strainer gasket (included with WHTV) into Tempering By-Pass Valve proved nut, and connect grooved nut to tempering valve hot inlet (marked "H" on valve body).

WARNING: If the tempering by-pass valve is not connected to a high-temperature line at the time of initial installation, factory-installed plug MUST remain in place and handle must remain in the closed position. Failure to do so can cause scalding, severe injury, or death.

To connect to an appropriate high-temperature appliance:

- **4.** Remove factory-installed plug from Tempering By-Pass Valve **1** hot outlet. Connect high-temperature water **k** piping to tempering by-pass valve **1** hot outlet.
- Proceed with additional WHTV installation instructions packaged with your WHTV or available at www.webstonevalves.com/instructions.



TBPV-0419 ©2019 NIBCO INC., All Rights Reserved.