

Beautiful[®] Kitchenware

Instruction Manual
Manual de instrucciones

*Make
Something
Beautiful™
♥ Drew*



16" x 12" Roaster with Rack
Asador de 16" x 12" con rejilla



The kitchen is my family's happy place. It's where we cook and eat and bake and laugh and share our most beautiful moments together. That's what inspired the creation of Beautiful, my new collection of easy-to-use kitchenware that you'll want to keep out on your kitchen counter. So whether your kitchen has flour all over the place from a kid's baking session or you're throwing an adult dinner party, I hope every step will be simple, delicious and beautiful!

 Drew

www.beautifulbydrew.com

Before Using for the First Time

- Remove all packaging and stickers from your cookware. Using a mild dish soap and soft cloth, wash in warm water. Rinse and dry thoroughly with a soft cloth. While cookware is dishwasher safe, hand washing is recommended to keep your cookware in the best condition.

Stovetop Use

- The cookware is compatible with all stovetops including induction. Be sure to match the bottom of the pan size to the burner size. Always heat your cookware gradually using a low-medium heat setting. High heat can damage or discolor cookware and overheating might cause food to burn. Do not boil dry, and do not leave cookware empty while on the stove.

CAUTION: Always use potholders while maneuvering your cookware on the stovetop.

Oven Use

- The cookware is oven safe to 500°F including the V-Rack.
CAUTION: Always use potholders to move your cookware or to grip the handles as they will become hot during cooking.

Cooking Utensils

- Silicone, wood, or heat resistant plastic cooking utensils are recommended.

Cleaning & Storage

- Allow your cookware to cool before cleaning. Never submerge or pour cold water on cookware while still hot- this can cause damage. You may soak cookware to remove burnt on food, but never use steel wool sponges or other sponges that may scratch. Do not use abrasive cleansers or detergents. Cookware is dishwasher safe, but hand washing in warm soapy water with a soft cloth is recommended to keep your cookware in the best condition. Always dry thoroughly before storing. Store in a dry place and avoid stacking or overcrowding.

Antes del primer uso

- Quitar todos los envoltorios y etiquetas tus utensilios de cocina. Lavar en agua tibia con jabón para platos suave y un paño suave. Enjuagar y secar completamente con un paño suave. Aunque los utensilios de cocina son aptos para el lavavajillas, se recomienda lavarlos a mano para mantenerlos en las mejores condiciones.

Uso en estufa

- Los utensilios de cocina se pueden utilizar con todas las hornallas, incluidas las de inducción. Asegurarse de que el tamaño del fondo de la sartén coincida con el tamaño del quemador. Calentar siempre los utensilios de cocina gradualmente usando un ajuste de calor bajo y medio. El fuego fuerte puede dañar o decolorar los utensilios de cocina y sobrecalentarlos puede provocar que los alimentos se quemen. No hervir en seco ni dejar los utensilios vacíos mientras están en la cocina.
ATENCIÓN: Siempre se deben utilizar agarraderas al maniobrar los utensilios de cocina en la hornalla.

Uso en el horno

- Los utensilios de cocina son seguros para el horno a 500 °F, Los utensilios de cocina son seguros para el horno a 500 °F, incluida la rejilla.
ATENCIÓN: Siempre se deben utilizar las agarraderas para mover los utensilios de cocina o para agarrar las asas laterales ya que se calentarán durante la cocción.

Utensilios de cocina

- Se recomienda usar utensilios de cocina de silicona, madera o plástico resistentes al calor, sin embargo, es seguro emplear utensilios de metal.

Limpieza y almacenamiento

- Dejar que los utensilios de cocina se enfríen antes de limpiarlos. No sumergir ni verter agua fría sobre los utensilios de cocina mientras aún estén calientes, ya que esto puede dañarlos. Se pueden remojar para quitar los restos quemados, pero no se deben emplear esponjas de lana de acero ni de ningún otro tipo, ya que podrían rayarlos. No utilizar limpiadores o detergentes abrasivos. Los utensilios de cocina son aptos para el lavavajillas, pero se recomienda lavarlos a mano en agua jabonosa tibia con un paño suave para mantenerlos en las mejores condiciones. Secar minuciosamente antes de guardar. Guardar en un lugar seco y evitar apilarlo o juntarlo con muchos otros utensilios.

Limited Lifetime Warranty

Sensio Inc. dba Made by Gather™ cookware is warranted to be free of defects in materials and workmanship under normal household use from the date of original retail purchase for the lifetime of the cookware. If your cookware should prove to be defective, we will replace it with the same item or one of equal or similar value, without charge to you, except for shipping and handling. This warranty is only valid for the original retail purchaser and is not transferable. Keep the original sales receipt, as proof of purchase is required to obtain warranty validation. To submit a warranty claim, please call our Customer Service Department, 1-866-832-4843, and be prepared to send a written explanation of the product problem, photographs of the product, your address, phone number and e-mail address, and a check or money order payable to Sensio Inc. to cover shipping and handling. This warranty does not cover damage caused by accident, misuse, abuse, alteration to product, commercial

use, use or care contrary to the operating and care instructions, damage from overheating, and damage from automatic dishwasher use on product lines not safe or intended for such dishwasher use, and it does not apply to normal wear and tear, scratches, stains, discoloration or other damage to external or internal surfaces that does not impair the functional utility of the product. This warranty expressly excludes all incidental and consequential damages. Some states do not allow the exclusion or limitation of incidental or consequential damages, and therefore the foregoing limitation or exclusion may not apply to you. For any questions, you may call our Customer Service Department toll-free at 1-877-775-3564.

Beautiful[®] Kitchenware

Garantía limitada de por vida

Los utensilios de cocina de Sensio Inc. bajo la marca comercial Made by Gather™, están garantizados contra defectos de materiales y mano de obra bajo el uso doméstico normal a partir de la fecha de compra original en una tienda minorista durante su vida útil. Si un utensilio de cocina resulta ser defectuoso, lo reemplazaremos por el mismo artículo o uno de valor igual o similar, sin cargo para usted, excepto los gastos de envío y gestión. La garantía solo es válida para el comprador minorista original a partir de la fecha de compra minorista inicial y no es transferible. Conserve el recibo de venta original como comprobante de compra para obtener la validación de la garantía. Para presentar una reclamación bajo la garantía, llame a nuestro Departamento de Atención al Cliente, al 1-866-832-4843, y esté listo para enviar una explicación por escrito del problema con el producto, fotografías del producto, su dirección, su número de teléfono y su dirección de correo electrónico,

así como un cheque o giro postal pagadero a Sensio Inc. para cubrir los gastos de envío y gestión. Esta garantía no cubre los daños causados por accidentes, mal uso, abuso, modificación del producto, uso comercial, uso o cuidado contrario a las instrucciones de uso y cuidado, daños por sobrecalentamiento y daños por uso de lavavajillas automáticos en líneas de productos no aptas o no diseñadas para usarse con dichos lavavajillas, y no se aplica al desgaste normal, rayones, manchas, decoloración u otros daños en las superficies externas o internas que no perjudiquen la utilidad funcional del producto. Esta garantía excluye expresamente los daños incidentales o consecuentes. Algunos estados no permiten la exclusión o limitación de daños incidentales o consecuentes y, por lo tanto, es posible que la limitación o exclusión anterior no se aplique en su caso. Si tiene alguna pregunta, llame a nuestro Departamento de Atención al Cliente al 1-877-775-3564.

Beautiful[®] Kitchenware

Make
Something
Beautiful™
♥ Drew



Sensio Inc.
dba Made by Gather™
New York, NY 10016/USA
www.beautifulbydrew.com

For customer service questions or comments
Para preguntas o comentarios para el servicio
de atención al cliente

1-877-775-3564
Made in China / Hecho en China

19552_19696 R0