## **KITCHEN MIXER**



- 2. Rubber washer
- 3. Fixing plate
- 4. Threaded tube
- 5. Fixing nut
- 6. Elexible hoses

## INSTALLATION INSTRUCTIONS

1. Install the O-Ring (part 1), flexible 2. Position the mixer over the hoses (part 6) and the threaded tube (part 4) onto the mixer, ensuring the O-ring is flat, the hoses are tight, and the threaded tube is secure.

## NOTE:

- · Hot is always on the left position.
- Some models use a horse-shoe connection.



3. Place the rubber washer (part 2) over the flexible hoses and push up until it is firm against the surface being mounted on, then push (part 3 + part 5) the fixing plate and fixing nut over the flexible hoses and tighten firmly and tighten screws where applicable.




center of the hole to be used

flexible hoses and threaded tube are pushed through first.

for mounting. Ensure the

4. Connect the flexible hoses to the isolating stop cocks (check that as the hoses are being tightened that they are not loose from the mixer body). Test for leaks and correct operation of the mixer.





Refer to www.meir.com.au for tolerances, flow rates and other additional information | 9