


The Oval C Photobooth Enclosure

Product Parts

1 - Hardware

- Top Angle Poles
- Bottom Angle Poles
- Top Shock-Corded Poles
- Bottom Shock-Corded Poles
- Vertical Shock-Corded Poles

2 - Graphic




Hardware Assembly

Step 1

Open all parts to the hardware and assemble the parts by matching up the symbols to the corresponding symbol illustrated in the image below.

NOTE:

Symbols represented above are for reference only and do not necessarily represent the symbols on your hardware.



Graphic Setup

Step 1

Set the assembled hardware on a clean surface.


Locate the left side of the graphic. Slide the left side of the frame into the left side of the graphic. With two or more people, start to drape the graphic over the top edge, beginning on the left side of the hardware, so that the seam rides along the top curved pole.

As you drape the graphic to the right, start to zip the graphic (zipper on bottom of graphic) to the hardware as you move further down the frame




NOTE:

The graphic is designed to fit the hardware precisely, as a result the graphic may appear to be too tight during the installation process (this is normal).



* START TO ZIP GRAPHIC AS YOU DRAPE.



* ZIPPER ON BOTTOM OF GRAPHIC

Storage

Store in a cool dry location.

Care

Machine wash cold, gentle cycle. Air Dry Only