

Quick Start Instructions:

1. Set the **ON/OFF** switch located on the right side of the radio to the **ON** position.
2. Pull out antenna and extend to its full length.
3. Insert 3 AA batteries (not included).
4. Plug the AC Adapter into the **POWER** jack on the back of the radio and the other end into a standard outlet.
5. Follow the prompts on the display screen using **▲** and **▼** to move through the options and **SELECT** to choose the desired option.
 - The radio will first display **WELCOME**, and then **SET LANGUAGE**
 - To **SET LANGUAGE** press the **SELECT** button:
 - Choose your language by pressing **▲** or **▼**, then **SELECT**.
 - To **SET LOCATION** press the **SELECT** button:
 - Press **▲** or **▼** until **SINGLE** is displayed, then press **SELECT**.
 - To **SET COUNTRY** press **SELECT** to program your county for position 01:
 - Press **▲** or **▼** to choose your country, then press **SELECT**.
 - Press **▲** or **▼** to choose your state or province, then press **SELECT**.
 - Press **▲** or **▼** to choose your county or area, then press **SELECT**.
 - To **SET TIME** press the **SELECT** button:
 - Set the time using **▶ ▲ ▼** and **◀** then press **SELECT**.
 - To **SET CHANNEL** press the **SELECT** button:
 - Tune the channel to the desired broadcast using **▲** or **▼**
 - To **SET VOLUME** press the **VOLUME UP** or **VOLUME DOWN** buttons.
6. To complete set-up, press the **SELECT** button.

