

# PowerFresh Deluxe

## 1979F

### Hot to Touch

Areas:  
Lower Area of Steam Mop  
Floor

It is normal for the lower front, sides, & back of the steam mop body to get hot, along with the foot area as that is where the steam comes out.

- This is the normal especially during extended use
- It shouldn't be hot from the water tank higher.
- If the consumer notes another area of the steam mop getting hot (ie, the handle etc.), or if they think it is unreasonably hot –

**External Support:** Contact BISSELL

It is also normal for the floor that has been mopped to be hot to the touch, especially immediately after passing over an area.

- Steam on the surface of the floor can be over 88 degrees Celsius and will diminish over time, cooling relatively quickly.

