



WORLD OF WATERSPORTS

www.wowwatersports.com

CASCADE POOL SLIDE OWNER'S MANUAL

IMPORTANT SAFETY INSTRUCTIONS READ AND FOLLOW ALL INSTRUCTIONS



WARNING



TO LESSEN YOUR RISK OF SERIOUS INJURY OR DEATH, FOLLOW THESE RULES:

To lessen your risk of serious injury or death. Follow these rules: Read the owner's manual before using your WOW Waterfall Slide.

- Assemble and disassemble by adults only.
- Not recommended for children under six years of age. Use only with mature, knowledgeable adult supervision.
- This product should never be used by children except under adult supervision. Keep children in sight while using the slide.
- Only 1 Person on the slide at a time.
- The Water Slide is designed for domestic in-ground swimming pools. For indoor and outdoor use.
- This Water Slide is designed to sit on the edge of the pool deck with water surface no more than 12 inches (30 cm) below the pool deck surface, and the float of the slide must be touching the water.
- Inflate all chambers of the Water Slide fully and firmly. Move slide to the in ground swimming pool area where the slide will be used. Then fill the water ballast chambers so the slide is stable before use.
- This is not a lifesaving device. This is not a personal flotation device.
- Never allow diving onto or from this product. Never dive or jump on product.
- Never slide head first or backwards.
- Slide feet first only.
- Do not walk or run up the slide.
- Always place slide in the deep end of the pool free from obstructions.
- Always wear a properly fitted life jacket (PFD) approved by your country's agency. USCG Type III. ISO. etc.
- Never place any body part through handles.
- Sliding, diving or jumping into shallow water can result in serious injury, broken neck, paralysis, or death.
- Do not stand on the top of the product.
- Do not rock slide from side to side to avoid accidental tipping.
- Make sure that all swimmers have cleared the landing zone before sliding. Ensure water entry point is clear of people or obstructions before going down slide.
- Do not climb up slide from water.
- Do not use under the influence of drugs or alcohol.
- Do not exceed manufacturer's recommended capacity.
- **MAXIMUM CAPACITY: 1 Person Weight Limit: 200 lbs / 90 kg**

RELEASE OF LIABILITY: By assembling and inflating this product, you agree that you have read and understand the entire World of Watersports' product manual, including all instructions and warnings contained in that material prior to using this product. You additionally agree that you will ensure any additional or subsequent users of this product will read and understand the entire owner's manual. Misuse or improper use of this product could result in risks, dangers and hazards which can result in serious injury or death. The risks and dangers that can be encountered through the improper use of this product can be avoided by reading and following the warning guidelines listed within the owner's manual and by proper use of this product. Your assembly and use of this product shall be evidence of your agreement, to the fullest extent permitted by law, to properly follow the instructions and abide by the warnings set forth within the product manual. Your assembly and use of this product shall also constitute a release, to the extent permitted by law, by you and by any third party permitted by you to use, in any manner, this product, to World of Watersports from any and all liability for any loss, damage, injury and/or expense that you or any user of this product may suffer as a result of the use of this product. This release shall extend to any loss, damage, injury or expense due to any cause whatsoever, including negligence or breach of contract on the part of World of Watersports and/or any party participating in the design and/or manufacture of this product. The terms of this release shall be effective and binding upon you, your heirs, next of kin, executors, administrators, assigns and representatives. Your assembly and use of this product shall constitute your agreement to assume and accept any or all known or unknown risks of injury to you and/or to third parties through the use of this product. World of Watersports and related parties have not made and hereby expressly deny any oral or written representation and/or warranty, including warranty for a particular purpose, other than what is set forth herein and in the World of Watersports' owner's manual.

This WOW Product Manual applies to the following item listed below please read and follow all warnings and information:

Product Name	Model#	Approximate Inflated Size	Person	Approximate Weight Limit
Cascade Pool Slide	22-WSL-4016-SC	97 in x 57 in x 45 in	1	200 lbs. 90 kg.
	22-WSL-4325-SC	246 cm x 144 cm x 114 cm		

Patent Pending Package Contents: 1 WOW SLIDE, 1 Repair Patch, 1 Product Manual

THE BEST AIR PUMPS TO USE TO INFLATE YOUR TUBE ARE THE FOLLOWING:

- 110 Volt Electric Pump - E.g. WOW 2.0 to 3.0 PSI High Pressure Air Pump or any 110 Volt Electric Pump with 2.0 to 3.0 PSI
- WOW Double Action Hand Pump or Foot Pump specifically designed for towables
- 12 Volt Pump pumps can also be used but their maximum output is only .8 psi so a secondary pump such a hand pump or foot pump will need to be used.
- Leaf Blower
- Shop Vac or vacuum with two-way switch
- Do NOT use an air compressor.



GENERAL INSTRUCTIONS:

- Two or more adults are recommended for setup. No tools are required for the assembly.
- The product must be installed on a flat and level surface at least 6.5 ft (2 meters) away from any structure or obstruction such as a fence, garage, house, overhanging branches, laundry lines or electrical wires.
- Locate the slide out of direct sunlight to reduce the likelihood of scalding. A product that faces north will receive the least direct sunlight.
- Carry the slide (in its package) to the selected site before inflating. Do not inflate the product and drag it since it may result in leaks or damage. If you do need to move the slide 2 people can lift the slide by using the handles located on each side of the slide. Please position the slide location in the deep end of the pool such that the slide exit is free from obstructions.
- Slowly unfold the product and inspect the product for rips, tears or punctures. Do not use if the product is damaged.

PROPER INFLATION: Proper inflation is the key to optimum performance and durability of this product. While in use, the cover should be taught with few wrinkles. If your product has no cover and is constructed out of PVC material only inflate until firm. Once inflated you should test whether there is enough air in the product by having an adult kneel on the product. If the product is properly inflated, then the adult will barely sink into the product while standing on top of it. If the product is under inflated damage can occur to the product while in use and the warranty will be voided. It is important to monitor the amount of air in the product once the item is in use. Continue to make sure that the product is properly inflated. **When not in use, be sure to remove some air from the product and put in a shaded area. If you leave a full product sitting in the sun it will cause the air inside to expand, causing serious damage to the seams and I-beams of the product. Check and adjust inflation levels each time you use the product.**

SETUP INSTRUCTIONS:

- Inflate the product with a air pump or foot air pump until the surface is firm to the touch. If there is any straining at the seams, the product is over-inflated. If any seam begins to strain, immediately stop the inflation and release air to reduce the pressure until signs of stress on the seam are gone. Do not over-inflate or use high pressure air compressor since it may result in seam leaks.

The air inside the slide will expand as the temperature increases: double check that the slide is not over inflated throughout the day.

- Find the valve and inflate the middle main body of the slide first until firm.
- Inflate the top right and left pontoon rails of the slide until firm.
- Inflate the slide's end bumper chamber until firm.
- Double check all inflation chambers are firm and close and secure all valves properly.
- Check the position of the slide location in relationship to the pools edge and water. Place the slide on the deck of the in-ground swimming pool such that the distance from the deck to the water surface is no greater than 12 inches (30 cm). **WARNING: Make sure the distance between the deck of the in-ground swimming pool and the water surface does not exceed 12 inches (30 cm) and the end bumper chamber is touching the water surface.**
- Locate the water ballast chambers on the bottom front left and right part of the slide. Find the valves on both water ballast chambers and open and fill with water. By filling the water ballast chambers the slide will offer more secure stable sliding by making the slide stay put and avoid shifting back as the slide is in use. **DO NOT TRY TO MOVE THE SLIDE WHILE THE WATER BALLAST CHAMBERS ARE FULL OF WATER. PLEASE DRAIN BEFORE MOVING THE SLIDE.**
- Connect the garden hose to sprayer valve and set water sufficient to adequately wet the sliding surface. Route the garden hose away from traffic to prevent any tripping hazard.

Do not modify this product and/or use accessories not supplied by the manufacturer.

SLIDE USE:

- Do not leave children unattended while slide is in use.
- Adults should closely supervise children when they are using the slide.
- Younger children may have difficulty climbing up the slide. Provide hands on help to younger children.
- Only one child on the slide at a time. Make sure pool area below slide is clear before allowing the next user to climb the slide.
- Do not use slide while wearing or holding sharp objects, such as jewelry, hair pin, that can puncture the product.
- Child should be positioned in the center of the sliding surface before going down the slide.



MAINTENANCE:

- You may clean your product using soap and water or mild detergent.
- Never use strong cleaning agents.
- The product, when clean and dry, can be deflated and stored in a cool, dry area out of direct sunlight.
- To deflate, simply unfasten the entire valve from the base. Note to unfasten all valves if you have multiple valves on your product
- Avoid storing this product in areas of extreme temperatures and please take precautions against animals and rodents.

PRODUCT STORAGE:

To prepare the product for storage please make sure that it is completely dry to prevent mildew and rot. Release all of the air from the chamber(s) and fold the product. If possible please store these products in a controlled temperature and do not expose the product to temperatures less than 40 degrees F. Cold temperature will damage the PVC material and cause it to crack at the folds.

Warranty Policy:

WARRANTY: WOW World of Watersports warrants, to the original purchaser only, that their high performance products, when used for normal recreational purposes, are free from defects in material and workmanship for a period of 1 year from the date of purchase. Any implied warranties are also limited in duration to the 1 year period from the original date of purchase. Our warranty excludes products for rental, for hire, and other uses not considered normal recreational purposes. WOW World of Watersports will not be held liable for incidental or consequential damages. Note: The above warranty is only applicable to products purchased inside the U.S.A. For all products purchased outside the U.S.A. the warranty is limited to 90 days.

The World of Watersports warranty does not cover:

- Failures caused by over-inflation and under-inflation
- Snags, tears, cuts and punctures obtained during normal use
- Items involved in accidents
- Fading from exposure to sunlight or weathering
- Misuse, abuse and neglect
- Improper storage

There are no warranties that extend beyond the description listed above. World of Watersports should not be held responsible in any way for any incidental and/or consequential damages. This warranty is in lieu of all other warranties.

**You should contact the retail store that you purchased the item from for warranty replacements.
If you have questions you may contact World of Watersports at customercare@wowwatersports.com
Phone: 1-844-969-9063**

**WOW WORLD OF WATERSPORTS
14301 FNB Parkway Ste 100
Omaha, NE 68154**

WOWWATERSPORTS.COM



⚠️WARNING: This product can expose you to chemicals such as Diisononyl Phthalate (DINP), which is known to the State of California to cause cancer. For more information go to www.P65Warnings.ca.gov