


- CARE GUIDE -

OUTDOOR MARKET THERMO MUG

350 ml / 12 oz



- CARE GUIDE -

Wash before use.

Hand wash only.

Keep out of reach of children.

Do not use in a microwave or oven.

Suitable for hot/cold drinks.

Keeps drinks warm/cold for up to 8h.

Outer surface may become hot.

Be careful when drinking hot beverages.

Even if the mug is cool to the touch, the drink may still be hot.

Pre-heat/pre-cool the mug with water for optimal temperature retention.

Do not overfill.

Allow hot liquids to cool slightly before sealing, to prevent pressure build-up.

Not suitable for carbonated liquids or citrus juices.

Ensure the lid is fully closed before drinking.

After drinking, close the silicone stopper securely.

Not 100% leak-proof, do not carry or store sideways.

Wash and dry after use to prevent rust.

In case of damaged lid, silicone stopper or container, please discard the product.

