
Installation and operation instruction

- 1. Prior to installation please ensure all the supply pipes have been through to remove any debris, avoid cartridge damage and blocking.
- 2. Put flange over the spout.
- 3. Wrap PTFE tape on the G 1/2 thread (or glue it), then screw on female G 1/2 thread in the wall.
- 4. Push flange close to the wall.



All products must comply with regulations of Local Water Authority as contained in their by-laws.

If the product is not supplied with balanced pressure, the mixer will notfunction properly. Non-return valves should be fitted on both the hot and cold feeds as close to the tap as possible (non-return valves not provided).