



OPERATOR MANUAL

IMPORTANT INFORMATION, KEEP FOR OPERATOR

888-994-7636, fax 888-864-7636
unifiedbrands.net

THIS MANUAL MUST BE RETAINED FOR FUTURE REFERENCE. READ, UNDERSTAND AND FOLLOW THE INSTRUCTIONS AND WARNINGS CONTAINED IN THIS MANUAL.

FOR YOUR SAFETY Do not store or use gasoline or other flammable vapors and liquids in the vicinity of this or any other appliance.


WARNING R290 flammable refrigerant in use. Improper installation, adjustment, alteration, service or maintenance can cause property damage, injury or death. Read the installation, operating and maintenance instructions thoroughly before installing or servicing this equipment.

NOTIFY CARRIER OF DAMAGE AT ONCE It is the responsibility of the consignee to inspect the container upon receipt of same and to determine the possibility of any damage, including concealed damage. Randell suggests that if you are suspicious of damage to make a notation on the delivery receipt. It will be the responsibility of the consignee to file a claim with the carrier. We recommend that you do so at once.

Manufacture Service/Questions 888-994-7636.

This manual provides information for:

DROP-IN HOT/COLD PAN RCHB SERIES



RETAIN THIS MANUAL FOR FUTURE REFERENCE

NOTICE: Due to a continuous program of product improvement, Randell reserves the right to make changes in design and specifications without prior notice.

NOTICE: Please read the entire manual carefully before installation. If certain recommended procedures are not followed, warranty claims will be denied.

MODEL NUMBER _____

SERIAL NUMBER _____

INSTALLATION DATE _____

The serial number is located on the underside of the cold pan near the drain.



SERIAL NUMBER XXXXXXXXX
MODEL NUMBER XXXXXXXXX
DESCRIPTION

EQUIPMENT DESCRIPTION

MODEL	LENGTH	WIDTH	PAN CAPACITY 12" X 20"	CUTOUT DIM		CONTROL PANEL		WATTS (HEATED)	HP	AMPS 60/1PH			SHIP WT (LBS)
				L	W	L	W			120V (REFRIG)	208V (HEATED)	240V (HEATED)	
RCHB-2	31-1/16"	26-1/8"	2	29-1/2"	25"	14"	6"	1100	1/4	3.5	5.3	4.5	110
RCHB-3	44-1/16"	26-1/8"	3	42-1/2"	25"	14"	6"	2200	1/4	3.5	10.6	9.2	135
RCHB-4	57-1/16"	26-1/8"	4	55-1/2"	25"	14"	6"	3300	1/4	3.5	15.9	13.8	160
RCHB-5	70-1/16"	26-1/8"	5	68-1/2"	25"	14"	6"	4400	1/4	3.5	21.2	18.3	185