CITI600 Pro - Firmware Instructions

1. Please update the firmware with PIXAPRO firmware update software G3. G3 can be downloaded from the essentialphoto website.

2. Firmware Version Checking: Switch the flash on, then press the "MENU" button and enter C.Fn custom functions. The firmware update version (e.g. Ver X.X) will be displayed on the LCD panel.

Version	Update Comment	Release Date
V1.3	1. To add compatibility with Flash Trigger for Leica --- ST-IV+L Wireless System	16/08/2022
V1.2	1. Initial Adjustments	05/06/2019

Note: For more information, please download the latest version of the instruction manual from: www.essentialphoto.co.uk/firmware/