

A large, light gray, stylized eye graphic is positioned on the left side of the page, partially cut off by the edge.

**R7** **S**

7 Inch High Brightness 3G-SDI Touch Screen Monitor  
With 3D LUTs And HDR

**Monitor Usage Guide**



# Contents

- PACKING LIST
- NOTICE
- QUICK START
- MENU OPERATION GUIDE
- IMPORT LUTS
- UPGRADE INSTRUCTION
- MENU GUIDE
- SPECIFICATIONS
- WARRANTY

## PACKING LIST

Before using this product, please check carefully whether everything is in the package.  
If there is anything missing, please contact us



Field Monitor



Storage Bag



Sun Hood



Snail Hot Shoe Mount



HDMI Micro



HDMI Mini



D-Tap



SD Card



Instruction Manual



Microfiber Cloth




## NOTICE

Thank you for buying the monitor. The content mentioned in this article concerns your safety and legitimate rights and responsibilities. Please read this article carefully before using this product, to ensure that the product has been properly set up. Failure to follow the instructions and warnings in this article may cause harm to you and the people around you, and damage the monitor or other surrounding items. The final interpretation rights of this document and all relevant documents of the monitor belong to Shenzhen Bestview Electronics Co., Ltd. as It is updated without notice. Please visit official website: [www.desview.com](http://www.desview.com) to get the latest product information.




By using this product, you are deemed to have read the disclaimer and warning carefully. Understand, acknowledge and accept all the terms and contents of this statement You promise to. Take full responsibility for using this product and possible consequences. You undertake to use this product only for legitimate purposes, and agree to this clause and any relevant regulations, policies and guidelines established by Desview.

Desview is not responsible for any loss, injury or any liability arising from direct or indirect use of the product. Users should follow all security guidelines including but not limited to this article.

## Body Size



# QUICK START



## MENU OPERATION GUIDE

**Attention:** This is a capacitive touch screen monitor, all option and content in menu can be operated by touch screen or use the knob button.



Double-tap screen to open the menu



Touch on the screen beside menu to exit menu interface



Pinch to Zoom



# IMPORT LUTS


1. Copy the Log file into the SD card.
2. Insert the SD card into the monitor's SD card slot.




3. Find the 'Custom Lut\_SD' in the LUT config menu, then touch "Search SD".




4. Open the LUT file you find.



## IMPORT LUTS

5. Choose the LUT you need to use, when the icon shows  , it indicates that the LUT has been imported successfully.




6. After import the LUT file, touch “Exit SD”, then pull out the SD card.

## UPGRADE INSTRUCTION


- 1.Copy the downloaded upgrade file into the SD card.
- 2.Insert the SD card into the monitor's SD card slot.



- 3.Find the “Update” in “System Config” menu, then click “OK”




The LED light which nears the power button will start flashing with red and green color.



- 4.The monitor will turn on automatic when the update is finished.

# MENU GUIDE

Exposure Assist 

False color

Zebra




Histogram

Waveform

Vectorscope

All Wave

HDR




# MENU GUIDE

Focus&Composition ^

Single Color



Peaking




Center Mark



Safe Area



Mark Ratio



Grid Lines



Audio Meters




# MENU GUIDE

LUT Config ^

LUT




Custom LUT\_sd



Display Setting ^

Aspect Ratio




Display Flip



Zoom




Pixel-to-Pixel




HV Delay




Freeze



Battery notification



Anamorphic



# MENU GUIDE

System Config ^

Menu Config

Color

Color Temperature

Backlight

Sound

Reset



Update

Status

Language

→ Duration

→ Brightness  Contrast 

Sharpness  Saturation 

→ Color Temperature     Red  Green  Blue 

→ Backlight      
Auto

→   Volume 

→

→

→ Input HDMI | Resolution NO signal | Scan Mode NO signal  
Frame NO signal | Color Temperature 6500K | Aspect Ratio Auto  
Backlight 80 | Volume 50 | R7SV3.2 20200110

## SPECIFICATIONS

Screen Size	7 inch
Machine Size	186x120.6x28.75mm
Weight	480g
Resolution	1920*1200
Contrast	1100:1
Brightness	1000
Viewing Angle	178°(H/V)
Backlight	LED
Material	ABS engineering plastic
Voltage	DC7-24V
Power	12W
Signal Input	HDMI1.4/3G-SDI
Signal Output	HDMI1.4/3G-SDI
Audio Output	3.5mm stereo headphone jack



# SPECIFICATIONS

## HDMI input/output signal format

720x480i&720x480p@59.94, 60Hz

720x576i&720x576p@50Hz

1280x720p@50, 59.94, 60Hz

1920x1080i@50, 59.94, 60Hz

1920x1080psf@24, 25, 29.97, 30Hz

1920x1080p@23.93, 24, 25, 29.97,30,  
50,59.94,60Hz

3840x2160p@24,25,30Hz

4096x2160p@24Hz

## 3G-SDI input/output signal format

720x480i@59.94, 60Hz

720x576i@50Hz

1280x720p@50, 59.94, 60Hz

1920x1080i@50, 59.94, 60Hz

1920x1080psf@24, 25, 29.97, 30Hz

1920x1080p@23.93, 24, 25, 29.97,30,  
50,59.94,60Hz

## WARRANTY INTRODUCTION

**Thank you for buying the product .You can enjoy the following services:**

- 1.The product will enjoy one year free warranty and free maintenance service for the whole life from the date of purchase.
- 2.During the warranty period, the company will be responsible for free maintenance if any fault is caused by the quality of the product itself under normal use.
- 3.If it is damaged due to improper use or other non product quality problem, it is necessary to charge maintenance fees as appropriate , even during the warranty period.(Time fee, material fee plus freight)
- 4.If the monitor exceeds the warranty period,we will continue to provide free technical support and maintenance advisory service in case of tehcnical or quality problem.
- 5.If you need to return or exchange for special reasons, you must keep the packaging intact and the accessories complete.
- 6.Any artificial damage, water entry,collision causing breakage to series of monitor is not included in warranty.

## WARRANTY CARD

### USER INFORMATION

name:

phone:

add:

### SALES INFORMATION

sale date:

distributor name:

distributor tel:

### REPAIR LOG

repair date:

repair name:

issue:

result:

repaired

not repaired

return

# Certificate

This product is strictly inspected and meets the standard and is allowed to be sold.

Examination clerk:

---

The contents are subject to update without notice



# FIELD MONITOR

