tala

Installation Guide

DAVID WEEKS FOR TALA

Thoughtful lighting, responsibly designed in London.

Thank you for making the switch to Tala. Discover the full Tala family at tala.co.uk

BEFORE STARTING

We advise the fitting of this ceiling rose and pendant to be performed by a qualified electrician. Please read through these instructions before commencing work, and keep them for future reference. Please take extreme care when carrying out these instructions.

IMPORTANT

This light fitting must be connected to the supply earth. If your lighting circuit does not have an earth, ask a qualified electrician to provide an earth facility. This light fitting is suitable for indoor use only. This fitting operates on 240V mains voltage.

WARNING


Always switch off electricity supply at the mains during installation and maintenance. We recommend that the fuse is withdrawn or the circuit breaker is switched off whilst work is in progress. Do not just turn off at the wall switch. All fittings must be installed in accordance with current Building Regulations and IEE Wiring Regulations.

RECOMMENDED EQUIPMENT


- Small flat head screwdriver
- Wire strippers
- Insulation tape


Further equipment may be required for fixing to your ceiling.

Please visit our website to see our recommended dimmers.



Echo Chandelier - Provided Components






STEP 1

Adjust the suspension cord 1 to your desired height by pulling it through the grip in the centre of the bracket.

Attach (A) to the ceiling using screws and plug. Always choose screws and plugs that are appropriate for the ceiling.





STEP 2


Adjust the Cable 2 to your desired length.

Using a flat head screw driver, tighten 'grub/set screw' on the cable grip $\fbox{3}$.

This will secure the cable in place. Maintain all double insulation.







STEP 5

Carefully insert your bulbs into the chandelier rotating each clockwise until tight. Take care not to tighten too much to avoid breakage.

CARE AND CLEANING

We recommend cleaning with a soft dry cloth. Do not use abrasive materials as these will damage the finish of the product.

WARRANTY AND AFTER-CARE

This product has a two-year warranty. If there appears to be a functional defect with the product during this time, please contact our team at customerservice@tala.co.uk.

Please note, the flexible cable attached to this luminaire cannot be replaced; if the cable is damaged, recycle the luminaire and seek a replacement.

This symbol $\frac{\mathbb{Z}}{}$ indicates that electrical and electronic equipment (WEEE) should not be mixed with general household waste.

For recovery and recycling, please take this product to a designated collection point where it will be accepted free of charge. Many retailers offer this in-store. Disposing of this product correctly will help save valuable resources and prevent any potential negative effects on human health and the environment.